


Operating Instruction BA 155 EN - Edition 07/20

Decentral frequency inverter EtaK2.0



Graphic: Lenze

TRANSLATION

The operating instructions are an integral part of the product. It contains important information for your safety. Make sure that the operating instructions are always available in a legible condition and complete at the assembly or installation site. Read the operating instructions carefully and observe their contents. If you have any questions, please contact Bauer Gear Motor before putting the drive into operation. Further documentation can be found on our homepage.

1 Table of Contents

Table of Contents

| | | |
|-----------|---|-----------|
| 1 | EU-Declaration of Conformity | 4 |
| 2 | About this documentation | 5 |
| 2.1 | Target group | 5 |
| 2.2 | Validity information | 5 |
| 2.3 | Safety instructions | 6 |
| 2.4 | Special safety instructions and application notes | 7 |
| 3 | Safety instructions | 8 |
| 3.1 | Safety instructions | 8 |
| 3.2 | Additional hazards for drive systems | 11 |
| 4 | Product description | 12 |
| 4.1 | Overview of system identification | 12 |
| 4.1.1 | Inverter Assembly | 13 |
| 4.2 | Technical data | 13 |
| 4.2.1 | General data and operating conditions | 13 |
| 4.2.2 | Rated data | 16 |
| 4.2.2.1 | Input data | 16 |
| 4.2.2.2 | Output data | 16 |
| 5 | Installation | 17 |
| 5.1 | Mechanical installation | 17 |
| 5.2 | Mains connection | 17 |
| 5.2.1 | Connection Conditions | 17 |
| 5.2.2 | Quick On Connector | 18 |
| 5.2.2.1 | Technical Data | 18 |
| 5.2.2.2 | Connecting the cable | 20 |
| 5.2.2.2.1 | Detaching the cable | 20 |
| 5.2.2.3 | Rewiring | 21 |
| 5.2.2.4 | Overview of connections | 21 |
| 5.2.3 | M12 – Power Connector | 21 |
| 5.2.3.1 | Technical Data | 21 |
| 5.2.3.2 | Connecting a cable | 23 |
| 5.3 | Connection for the Communication Unit (CU) | 24 |
| 5.3.1 | Removing the communication unit from the wiring unit | 24 |
| 5.3.2 | Disconnecting the circuit board & mounting the screw connection | 24 |
| 5.3.3 | Rotating the communication unit | 25 |
| 5.3.4 | Connections for I/O | 27 |
| 5.3.5 | Connections for AS-i K2ADGFCAxxx | 28 |
| 5.3.6 | Connections for CAN K2ADGFCCxxx | 29 |
| 5.3.7 | Connections for PROFIBUS K2ADGFCPxxx | 30 |
| 5.3.8 | Connections for PROFINET K2ADGFCRxxx | 30 |
| 5.3.9 | Connections for ETHERNET/IP K2ADGFCGxxx | 31 |
| 5.3.10 | Connections for EtherCAT K2ADGFCTxxx | 31 |

1 Table of Contents

| | | |
|----------|--|-----------|
| 5.3.11 | Connections for standard I/O | 32 |
| 5.3.11.1 | Type 1 | 32 |
| 5.3.11.2 | Type 2 | 32 |
| 5.3.11.3 | Type 3 | 32 |
| 5.3.12 | Connection for the safety option | 32 |
| 5.3.13 | Wiring diagram for Standard I/O | 33 |
| 5.3.14 | Wiring diagram for AS-i, CAN, PROFIBUS, PROFINET, EtherNet/IP, EtherCAT | 33 |
| 5.3.15 | Wiring diagram for Safety + (AS-i, CAN, PROFIBUS, PROFINET, EtherNet/IP, EtherCAT) | 33 |
| 5.3.16 | Wiring diagram for the safety option | 34 |
| 5.4 | Measures when drive is used in IT systems | 34 |
| 5.5 | Settings | 35 |
| 6 | Commissioning | 37 |
| 6.1 | Preconditions for initial switch-on | 37 |
| 6.2 | Parameter setting | 39 |
| 6.3 | Change parameter settings with PC and easy starter software | 40 |
| 6.4 | Keypad | 42 |
| 6.4.1 | Keypad display and control elements | 42 |
| 6.4.2 | General operation | 44 |
| 6.4.3 | Menu structure | 44 |
| 6.4.4 | Overview of the commissioning steps with keypad | 44 |
| 6.5 | Commissioning | 48 |
| 6.5.1 | User menu | 49 |
| 7 | Troubleshooting | 50 |
| 7.1 | Drive diagnostics via the integrated display | 50 |
| 7.2 | Diagnostic codes | 51 |

1 EU-Declaration of Conformity

EU Declaration of Conformity



Low Voltage Directive 2014/35/EU
EMC Directive 2014/30/EU

Bauer Gear Motor GmbH

Postfach 10 02 08
73726 Esslingen (Germany)
Eberhard-Bauer-Str. 37
73734 Esslingen (Germany)
Telephone: +49 (0)711 35 18 0
Fax: +49 (0)711 35 18 381
Email: info@bauergears.com
Website: www.bauergears.com

B 320.0790-01 Version: 07/20

Bauer Gear Motor GmbH

Eberhard-Bauer-Str. 37, 73734 Esslingen (Germany)

hereby declares on its sole responsibility conformity of the following products:

Geared motors with an attached frequency converter in the Eta-K2.0 series

with the requirements of the European Directives

DIRECTIVE 2014/35/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 26 February 2014 on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits.
Published on 29 March 2014 in the Official Journal of the EU L96/357.

DIRECTIVE 2014/30/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility.
Published on 29 March 2014 in the Official Journal of the EU L96/79.

The object of declaration as described above is in conformity with the pertinent harmonisation legislation of the Union, demonstrated by compliance with the following harmonised standards

EN 60034-1:2010 / AC:2010
EN 60034-5:2001 / A1:2007
EN 60529:1991 / A1:2000 / A2:2013
EN 61800-3:2004 / A1:2012
EN 61800-5-1:2007

Additional information:

Compliance with the directive requires correct installation of the products, observance of the specific installation instructions and the product documentation. The installer is responsible for the final EMC properties of the device, system or installation.

Esslingen 01 July 2020

Bauer Gear Motor GmbH

N. Halmuschi
(Managing Director)

P. Cagan
(Quality Director)

This declaration does not constitute a guarantee of features or performance with regard to product liability. The technical documentation is produced and administered by Bauer Gear Motor GmbH.

CERT-EG5-KonfErk_EMV_NSF_Eta-K2-0_B320_0790_01_EN

2 About this documentation

2.1 Target group

This documentation is directed at qualified skilled personnel according to IEC 60364. Qualified skilled personnel are persons who have the required qualifications to carry out all activities involved in installing, mounting, commissioning, and operating the product.

2.2 Validity information

These instructions are valid for EtaK2.0 controllers with the following type designation:

| Type designation | From HW | From SW |
|------------------|---------|---------|
| K2Axxx | A | 01.00 |

Further information on the type code can be obtained from the "Product description" chapter.

2 About this documentation

2.3 Safety instructions

The following pictographs and signal words are used in this documentation to indicate dangers and important information.

Structure of safety instructions:






Danger!

(characterises the type and severity of danger)




Note text

(describes the danger and gives information about how to prevent dangerous situations)



| Pictograph and signal word | Meaning |
|---|---|
|  Danger! | Danger of personal injury through dangerous electrical voltage Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. |
|  Danger! | Danger of personal injury through a general source of danger Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. |
|  STOP! | Danger of property damage Reference to a possible danger that may result in property damage if the corresponding measures are not taken. |

2 About this documentation

Application notes

| Pictograph and signal word | Meaning |
|---|--|
|  Note! | Important note to ensure troublefree operation |
|  Tip! | Useful tip for simple handling |
|  Info! | Reference to another documentation |

2.4 Special safety instructions and application notes

| Pictograph and signal word | Meaning |
|---|--|
|  Warnings! | Safety note or application note for the operation according to UL or CSA requirements. The measures are required to meet the requirements according to UL or CSA. |
|  Warnings! | |

3 Safety instructions

3.1 Safety instructions



Danger!

Dangerous voltage

- ▶ The power terminals carry dangerous voltages for up to 3 minutes after mains disconnection.

Possible consequences:

- ▶ Death or severe injury if the power terminals are touched.

Protective measures:

- ▶ Switch off the mains voltage and wait at least 3 minutes before starting to work on the device.
- ▶ Check that all power terminals are deenergised.

Warning by symbols

| Icon | Description |
|------|--|
| | Long discharge time: All power terminals remain live for up to 3 minutes after mains disconnection! |
| | High leakage current: Carry out fixed installation and PE connection in accordance with EN 61800-5-1! |
| | Electrostatic sensitive devices: Before working on the device, the staff must ensure to be free of electrostatic charge! |
| | Hot surface: Use personal protective equipment or wait until devices have cooled down! |

3 Safety instructions

Please also refer to important additional information about the equipment as well as the safety technology found under: www.bauergears.com/downloads/etak20-software.

Original - English



Warnings!

- ▶ These devices are suitable for field wiring.
- ▶ Intended for use with 75 °C wire.
- ▶ Intended for use with copper conductors only.
- ▶ Suitable for use in a surrounding air temperature of 45 °C, and – additionally 60 °C when de-rating rules are followed.
- ▶ Hot surface. Risk of burn.
- ▶ Should this device be mounted on a motor, the combination needs to be suitable for the type rating.
- ▶ The supply terminals are to be tightened to:
 - For model suffix's 371, 551, 751, 112, 152 tighten to 4.4 – 5.3 lb-in.
 - For model suffix's 222, and 302, tighten to 7 lb-in.
- ▶ These devices are suitable for use on a circuit capable of delivering not more than 200000 rms symmetrical amperes, 480 V maximum
 - When protected by CC, R, T, or J class fuses or
 - When protected by a circuit breaker having an interrupting rating not less than 200 000 rms symmetrical amperes, 480 V maximum.
- ▶ Use fuses and circuit breakers only.
- ▶ Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.
- ▶ The opening of branch circuit protective devices may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current carrying parts and other components, the controller should be examined and replaced if damaged.
- ▶ These devices provide overload protection rated for 125 % of the rated FLA.

CAUTION!

- ▶ Risk of electric shock. Please allow 3 minutes for the internal capacitors to discharge.

3 Safety instructions

Original - French



Avertissements

- ▶ Ces équipements sont adaptés à un câblage à pied d'oeuvre.
- ▶ Utiliser des conducteurs 75 °C.
- ▶ Utiliser exclusivement des conducteurs en cuivre.
- ▶ Convient à une utilisation à une température ambiante maximale de 45 °C ainsi que – 60 °C en cas d'application des règles de réduction de puissance.
- ▶ Température élevée en surface. Risque de brûlure.
- ▶ En cas de montage de l'équipement sur le moteur, la combinaison doit être conforme à la qualification du type.
- ▶ Couples de serrage des bornes réseau :
 - Pour les types contenant le suffixe 371, 551, 751, 112, 152 : 0,5 à 0,6 Nm.
 - Pour les types contenant le suffixe 222 et 302 : 0,8 Nm.
- ▶ Convient aux circuits non susceptibles de délivrer plus de 200 000 ampères symétriques eff., maximum 480 V
 - Protection par des fusibles CC de calibre R, T ou J ; ou
 - Protection par disjoncteur à pouvoir de coupure nominal d'au moins 200000 ampères symétriques eff., maximum 480 V.
- ▶ Utiliser exclusivement des fusibles et des disjoncteurs.
- ▶ La protection statique intégrée n'offre pas la même protection qu'un disjoncteur. Une protection par disjoncteur externe doit être fournie, conformément au National Electrical Code et aux autres dispositions applicables au niveau local.
- ▶ Le déclenchement des dispositifs de protection du circuit de dérivation peut être dû à une coupure qui résulte d'un courant de défaut. Pour limiter le risque d'incendie ou de choc électrique, examiner les pièces porteuses de courant et les autres éléments du contrôleur ; les remplacer s'ils sont endommagés.
- ▶ Ces équipements intègrent une protection contre les surcharges conçue pour se déclencher à 125 % de l'intensité assignée à pleine charge.

ATTENTION !

- ▶ Risque de choc électrique. Patientez 3 minutes pour permettre aux condensateurs internes de se décharger.

3 Safety instructions

3.2 Additional hazards for drive systems

The drive system and all the associated components for the control system and the drive have been approved for use on an industrial or commercial mains connection. Additional measures and/or a different configuration will be required if a connection to a public network is desired.

All necessary work involving these components must be carried out by suitably qualified technicians who have the supplied service manuals and product documentation, among other things, when performing any corresponding work and who must follow these consistently.


Machine manufacturers must perform a risk assessment in accordance with applicable directives (e.g. the EC Machinery Directive) to assess the residual risks originating from components such as the control system or the drive in a drive system.

1. The following situations may cause involuntary movements in driven machine parts during commissioning, operation, maintenance and repair:
 - Hardware and/or software errors in the sensors, control system, actuators, cables and connections
 - Reaction times for the control system and the drive
 - Operation and/or environmental conditions outside the specification
 - Condensation/conductive contamination
 - Parameterisation, programming, cabling and installation errors
 - Use of wireless devices/mobile phones in the immediate vicinity of the control system
 - External influences/damage

2. The following situations may cause hazardous shock voltages:
 - Component failure
 - Influence during electrostatic charging
 - Voltage induction in moving motors
 - Operation and/or environmental conditions outside the specification
 - Condensation/conductive contamination
 - External influences/damage

4 Product description

4.1 Overview of system identification




Photos: Bauer Gear Motor, Lenze

| | | |
|----------|--------------------------------------|-----------------|
| A | EtaK2.0 | 0.37 ... 3.0 kW |
| B | EtaK2.0 | 4.0 ... 7.5 kW |
| C | EtaK2.0 Field Package without switch | 0.37 ... 3.0 kW |
| D | EtaK2.0 Field Package with switch | 0.37 ... 3.0 kW |
| E | EtaK2.0 Field Package without switch | 4.0 ... 7.5 kW |

4 Product description

4.1.1 Inverter Assembly



Graphic Lenz

4.2 Technical data

4.2.1 General data and operating conditions

| Conformity and approval | | | |
|-------------------------|----------------|--|--|
| Conformity | | | |
| CE | 2006/95/EG | LowVoltage Directive | |
| ECA | TP TC 004/2011 | On safety of low voltage equipment | Eurasian Conformity TR CU: Technical Regulation of Customs Union |
| ECA | TP TC 020/2011 | Electromagnetic compatibility of technical means | Eurasian Conformity TR CU: Technical Regulation of Customs Union |
| Approval | | | |
| UR | UL508C | Power Conversion Equipment, File No. E170350 | |
| cUR | C22.2 No 14 | | |

4 Product description

| Protection of persons and equipment | | | |
|---|--------------|---|--|
| Enclosure | EN 60529 | IP65 optional: IP66 | in ready-for-use state: Close unused bores for cable glands with blanking plugs! Close unused connectors with protection covers or blanking plugs! |
| | NEMA 250 | Protection according to: • Type 4 | |
| (Earth) leakage current | EN 61800-5-1 | > 3.5 mA AC > 10 mA DC | Observe the regulations and safety instructions! |
| Total fault current | | In TN systems the following earth-leakage circuit breakers can be used: | |
| Motor mounting | | K2A003 ... K2A015 | 30 mA, type B |
| | | K2A022 ... 2A075 | 300 mA, type B |
| Wall mounting | | K2A003 ... 2A075 | 300 mA, type B |
| Additional equipotential bonding | | M5 thread with terminal in the WU for connection of a 16 mm PE cable. | |
| Protective insulation of control circuits | EN 61800-5-1 | Safe isolation from mains by double (reinforced) insulation. | |
| Insulation resistance | EN 61800-5-1 | Site altitude | |
| | | 0...2000 m | Overvoltage category III |
| | | 2000...4000 m | Overvoltage category II |
| Short-circuit strength | EN 61800-5-1 | Connection: | |
| | | Motor | To a limited extent, the controller is inhibited, error acknowledgement required |
| | | Motor holding brake, brake resistor | No |
| | | PTC, control terminals | Full |
| Earth-fault strength | EN 61800-5-1 | Connection: | |
| | | Motor (at controller enable) | To a limited extent, the controller is inhibited, error acknowledgement required |
| | | Motor (during operation) | No |
| | | Brake resistor, PTC | No |
| Starting current | | $\leq 2 \times I_N$ | |

4 Product description

| Supply conditions | | | |
|---|--------------------|--|---|
| Mains connection | | | |
| Power system | | | |
| TT, TN (with an earthed neutral) | | Operation permitted without restrictions. | |
| IT | | Implement the measure described for IT systems (remove IT screw). The machine/system manufacturer is responsible for compliance with EMC requirements for noise emission (EN 61800-3) for the machine/plant! Operation with an integrated safety system is not permissible. | |
| Motor connection | | | |
| Motors | EN 60034 | Only use motors suitable for inverter operation. Insulation resistance: at least $\hat{u} \geq 1.5$ kV, at least du/dt 5 kV/ μ s | |
| Length of the motor cable | | < 20 m motor cable shielded | |
| Ambient conditions | | | |
| Climatic | | | |
| Storage | IEC/EN 60721-3-1 | 1K3 (-30...+ 60 oC) | |
| Transport | IEC/EN 60721-3-2 | 2K3 (-30...+ 75 oC) | |
| Operation | IEC/EN 60721-3-3 | 3K3 (-30...+ 55 oC) Operation at 4 kHz: > +45 °C: Reduce the rated output current by 2.5 %/°C. Operation at 8/16 kHz: > +40 °C: Reduce the rated output current by 2.5 %/°C. | |
| Site altitude | | < 4000 m amsl Above 1000 m amsl reduce the rated output current by 5 %/ 1000 m. | |
| Pollution | IEC/EN 61800-5-1 | Degree of pollution 2 | |
| Mechanical | | | |
| Vibration resistance (9.81 m/s ² =1 g) | | | |
| Motor mounting | Germanischer Lloyd | General conditions: Acceleration resistant up to 2 g | |
| | IEC/EN 60721-3-3 | 3M6 | |
| Wall mounting with E84DZMAWE1 | Germanischer Lloyd | General conditions: Acceleration resistant up to 2 g | |
| | IEC/EN 60721-3-3 | 3M6 | |
| Mounting conditions | | | |
| Mounting place | | | |
| Motor mounting | | Standard | |
| Wall mounting | | With optional wall adapter | Ensure convection cooling in the niches! |
| Mounting position | | | |
| Wall mounting | | | |
| K2A003...K2A030 | | Vertical, cooling fins at the top | Arrangement of several devices only to the sides, so that the convection cooling remains ensured! |
| K2A030...K2A075 | | Optional | |

4 Product description

4.2.2 Rated data

4.2.2.1 Input data

| Basis of the data | | | |
|-------------------|------------------------|------------------------------|----------------------------|
| Mains | Voltage $U_{LN}[V]$ | Voltage range $U_{LN}[V]$ | Frequency range $f[Hz]$ |
| 3/PE AC | 400 | 320 - 0 % ... 440 + 0 % | 45 - 0 % ... 65 + 0 % |
| 3/PE AC | 480 | 432 - 0 % ... 528 + 0 % | 45 - 0 % ... 65 + 0 % |

| | Voltage [V] | Frequency [Hz] | Rated current [A] | | Number of phases |
|--------|----------------|-------------------|-------------------|---------------|---------------------|
| | | | up to +45 °C* | up to +55 °C* | |
| K2A003 | 400/480 | 50/60 | 1.3/1.1 | 1.0/0.8 | 3 |
| K2A005 | 400/480 | 50/60 | 1.8/1.5 | 1.4/1.1 | 3 |
| K2A007 | 400/480 | 50/60 | 2.4/2.0 | 1.8/1.5 | 3 |
| K2A011 | 400/480 | 50/60 | 3.2/2.7 | 2.4/2.0 | 3 |
| K2A015 | 400/480 | 50/60 | 3.8/3.1 | 2.9/2.3 | 3 |
| K2A022 | 400/480 | 50/60 | 5.6/4.6 | 4.2/3.5 | 3 |
| K2A030 | 400/480 | 50/60 | 7.2/5.9 | 5.4/4.4 | 3 |
| K2A040 | 400/480 | 50/60 | 9.3/7.7 | 7.0/5.8 | 3 |
| K2A055 | 400/480 | 50/60 | 12.8/10.6 | 9.6/8.0 | 3 |
| K2A075 | 400/480 | 50/60 | 16.3/13.5 | 12.3/10.1 | 3 |

*Ambient temperature, switching frequency 4 kHz

4.2.2.2 Output data

| | Voltage [V] | Frequency [Hz] | Rated current [A] | | Number of phases |
|--------|----------------|-------------------|-------------------|---------------|---------------------|
| | | | up to +45 °C* | up to +55 °C* | |
| K2A003 | 0 ... 400/480 | 0 ... 300 | 1.3/1.1 | 1.0/0.8 | 3 |
| K2A005 | 0 ... 400/480 | 0 ... 300 | 1.8/1.5 | 1.4/1.1 | 3 |
| K2A007 | 0 ... 400/480 | 0 ... 300 | 2.4/2.0 | 1.8/1.5 | 3 |
| K2A011 | 0 ... 400/480 | 0 ... 300 | 3.2/2.7 | 2.4/2.0 | 3 |
| K2A015 | 0 ... 400/480 | 0 ... 300 | 3.9/3.2 | 2.9/2.4 | 3 |
| K2A022 | 0 ... 400/480 | 0 ... 300 | 5.6/4.7 | 4.2/3.5 | 3 |
| K2A030 | 0 ... 400/480 | 0 ... 300 | 7.3/6.0 | 5.4/4.5 | 3 |
| K2A040 | 0 ... 400/480 | 0 ... 300 | 9.5/7.9 | 7.1/5.9 | 3 |
| K2A055 | 0 ... 400/480 | 0 ... 300 | 13.0/10.8 | 9.8/8.1 | 3 |
| K2A075 | 0 ... 400/480 | 0 ... 300 | 16.5/13.7 | 12.4/10.3 | 3 |

*Ambient temperature, switching frequency 4 kHz


5 Installation

5.1 Mechanical installation

Please refer to the full version of the technical manual for detailed information and instructions. This is available for download at: www.bauergears.com/downloads/etak20-software

5.2 Mains connection

Please refer to the full version of the technical manual for detailed information and instructions. This is available for download at: www.bauergears.com/downloads/etak20-software



Graphic: Lenze

5.2.1 Connection Conditions

| | F | | | L1, L2, L3/U, V, W | | | PE | | | T1, T2 | | |
|--------|---------|----|-----|-----------------------------|------|-----------------|-----------------------------|------|-----------------|-----------------------------|------|-----------------|
| | EN60204 | | UL | [mm ²] [AWG] | [mm] | [Nm] [ib-in] | [mm ²] [AWG] | [mm] | [Nm] [ib-in] | [mm ²] [AWG] | [mm] | [Nm] [ib-in] |
| | [A] | | [A] | | | | | | | | | |
| K2A003 | C16 | 16 | 15 | 1...4.0 | 10 | 0.5 | 1...4.0 | 10 | 1.7 | 1.5 | 10 | 0.5 |
| - | C32 | 32 | | 18...10 | | 4.4 | 18...10 | | 15 | 16 | | 4.4 |
| K2A015 | | | | | | | | | | | | |
| K2A022 | C16 | 16 | 15 | 1..6.0 | 10 | 0.8 | 1...16 | 10 | 1.7 | 1...6 | 10 | 0.8 |
| - | C32 | 32 | 25 | 18...8 | | 7.0 | 18...8 | | 15 | 18...8 | | 7.0 |
| K2A030 | | | | | | | | | | | | |
| K2A040 | C20 | 20 | 20 | 1...16.0 | 10 | 1.4 | 1...16 | 10 | 1.7 | 1...6 | 10 | 0.8 |
| - | C50 | 50 | 50 | 18...6 | | 12 | 18...6 | | 15 | 18...8 | | 7.0 |
| K2A075 | | | | | | | | | | | | |

Graphic: Lenze

5 Installation

5.2.2 Quick On Connector



Photo: Bauer

5.2.2.1 Technical Data

| General: | |
|--|------------------------------|
| Name: | QPD W 3PE2.5 9-14 M25 0.5 BK |
| Design: | QPD 4x2.5 |
| Color: | black |
| Locking type: | Screw locking |
| Connection method: | QUICKON connection |
| Connection type: | IDC connection |
| Number of positions: | 4 |
| Note number of positions: | 3+PE |
| Wrench size, union nut: | 22 mm |
| Tightening torque, union nut: | 5 Nm |
| Tightening torque, counter nut: | 5 Nm |
| Wrench size, counter nut: | 27 mm |
| Number of connections: | 10 |
| Conductor cross section flexible min.: | 1 mm ² |
| Conductor cross section flexible max.: | 2.5 mm ² |
| Conductor cross section solid min: | 1 mm ² |
| Conductor cross section solid max: | 2.5 mm ² |
| Conductor cross section AWG min: | 16 |
| Conductor cross section AWG max: | 14 |

| Cable: | |
|---|------------------------------------|
| Structure of individual stranded wire in acc. with VDE 0295 / smallest wire diameter: | VDE 0295 class 1 to 6/min. 0.15 mm |
| Wire insulation material: | PVC/PE/TPE/rubber |
| Wire diameter including insulation: | 2.5 mm - 3.8 mm |
| External cable diameter: | 9 mm - 14 mm |
| Conductor cross section: | 2.5 mm ² |
| Position marking: | 1, 2, 3, PE |

| Ambient conditions: | |
|--|-------------------|
| Degree of protection: | IP66 |
| Degree of protection: | IP68 (2 m / 24 h) |
| Degree of protection: | IP69K |
| Ambient temperature (operation): | -40 °C - 100 °C |
| Ambient temperature (storage/transport): | -40 °C - 80 °C |
| Temperature when conductor connected: | -5 °C - 50 °C |

5 Installation

Electrical characteristics:

| | |
|------------------------------|--------|
| Nominal current I_N : | 20 A |
| Rated current: | 20 A |
| Rated voltage (III/3): | 690 V |
| Rated voltage (III/2): | 1000 V |
| Rated voltage (II/2): | 1000 V |
| Rated surge voltage (III/3): | 6 kV |
| Rated surge voltage (III/2): | 8 kV |
| Rated surge voltage (II/2): | 8 kV |

Mechanical characteristics:

| | |
|-------------------------|---------|
| QUICKON connectability: | max. 10 |
|-------------------------|---------|

Material data:

| | |
|---|---------------|
| Contact material: | Cu |
| Contact surface material: | silver-plated |
| Contact carrier material: | PA |
| Insulating material: | PA |
| Flammability rating according to UL 94: | V0 |
| Overvoltage category: | III |
| Degree of pollution: | 3 |

Standards and Regulations:

| | |
|---|----|
| Flammability rating according to UL 94: | V0 |
|---|----|

Ordering Information:

| | |
|---------------|------------------------------|
| Manufacturer: | Phoenix Contact |
| Type: | QPD W 3PE2,5 9-14 M25 0,5 BK |
| Item-no.: | 1582175 |

5 Installation


5.2.2.2 Connecting the cable

WARNING:

The installation and startup must only be carried out by experts observing the country-specific regulations.

1. Strip approx. 60 mm off the cable.
2. Loop the PE wire around the live wires.
 - As a result, the protective conductor will be pulled out of the terminal block last if strong tension is exerted on the cable.
3. Insert the cable into the QUICKON nut and fix the wires in the conductor support of the splice body.
4. Cut off the wires with a diagonal cutter flush on the splice body.
5. Screw the QUICKON nut together with the QPD component (tightening torque: 5 Nm).

As a guide, numerals I, II, and III can be found on the connection. The QUICKON nut must be screwed on so tightly that it cannot be released again by hand.



Fotos: Phoenix

5.2.2.2.1 Detaching the cable

- To detach the cable, completely unscrew the QUICKON nut.
- Use a commercial bladed-type screwdriver (blade width 3 mm ... 4 mm) to remove the splice body from the connection dome.

The QUICKON connector is connected as described above. It features a capacitive PE contact. It is polarized to prevent mismatching and features touch-proof protection according to DIN EN 50274.


WARNING: Always de-energize the connector before connecting or disconnecting it.

5 Installation

5.2.2.3 Rewiring

The QUICKON connection with QUICKON nut and IDC terminal blocks can be rewired up to ten times with the same cable cross section. For this, the cable must be cut off and the connection has to be re-established.

5.2.2.4 Overview of connections

| Connection number | Function |
|--|----------|
| 1 | L1 |
| 2 | L2 |
| 3 | L3 |
|  | PE |

5.2.3 M12 – Power Connector

5.2.3.1 Technical Data

Environmental conditions:

Ambient temperature (operation): -25 °C - 85 °C (plug/bushing)

Ambient temperature (operation): -40 °C - 85 °C (no mechanical operation)

Protection code: IP67

General:



Photo: Bauer

NOTE:

The electrical and mechanical data specified assume that the connector pair is correctly locked and mounted. If the connector is unlocked and if there is a danger of contamination, the connector must be sealed using a protective cap > IP54. Influences arising from stranded wires, cables or PCB assembly must also be taken into consideration.

5 Installation

| General: | |
|------------------------------|-----------------------------------|
| Rated current at 40 °C: | 12 A |
| Rated voltage: | 630 V |
| Rated surge voltage: | 6 kV |
| Number of positions: | 4 |
| Number of positions: | ≥ 100 MOhm |
| Coding: | S - Power |
| Standards/regulations: | M12-connector |
| Signal type/category: | Power |
| Status display: | No |
| Overvoltage category: | III |
| Degree of pollution: | 3 |
| Test voltage: | 6 kV |
| Connection method: | Individual wires |
| Insertion/withdrawal cycles: | > 100 |
| Torque: | 3 Nm ... 4 Nm (Installation-side) |
| Mounting type: | Front mounting M16 x 1.5 |

| Material: | |
|---|---------------------------|
| Flammability rating according to UL 94: | V0 |
| Contact material: | CuZn |
| Contact surface material: | Ni/Au |
| Contact carrier material: | PA |
| Material, knurls: | CuZn alloy, nickel-plated |
| Sealing material: | FKM |

| Cable: | |
|----------------------------------|---|
| Cable type: | PP stranded wire |
| Conductor cross section: | 1.5 mm ² |
| AWG signal line: | 16 |
| Wire colors: | Black 1, black 2, black 3, green/yellow |
| Material conductor insulation: | PP |
| Conductor material: | Bare Cu stranded wires |
| Standards/specifications: | M12 connector |
| Flame resistance: | in acc. with UL FT-2 |
| Halogen-free: | According to IEC 60754-1 |
| Ambient temperature (operation): | -40 °C - 90 °C (cable, fixed installation) |
| Ambient temperature (operation): | -30 °C - 90 °C (cable, flexible installation) |

| Standards and Regulations: | |
|---|--------------------------|
| Standard designation: | M12-connector |
| Halogen-free: | According to IEC 60754-1 |
| Flame resistance: | in acc. with UL FT-2 |
| Flammability rating according to UL 94: | V0 |

| Ordering Information: | |
|------------------------------|-------------------------------|
| Manufacturer: | Phoenix Contact |
| Type: | SACC-E-M12MSS-4CON-M16/0,5 PE |
| Item-no.: | 1424139 |

5 Installation

5.2.3.2 Connecting a cable


Schematic diagram



Graphic: Phoenix

Connector pin assignment of M12 plug, 4-pos., S-coded, view of pin side M12 flush-type plug.

Circuit diagram




Graphic: Phoenix

| Pin Number | Function |
|------------|----------|
| 1 | L1 |
| 2 | L2 |
| 3 | L3 |
| PE | PE |

5 Installation


5.3 Connection for the Communication Unit (CU)

5.3.1 Removing the communication unit from the wiring unit



Graphic: Lenze


5.3.2 Disconnecting the circuit board & mounting the screw connection



Graphic: Lenze

5 Installation


5.3.3 Rotating the communication unit



Graphic: Lenze


5 Installation

0.37 ... 3.0 kW



Graphic: Lenze


4.0 ... 7.5 kW



Graphic: Lenze

5 Installation

5.3.4 Connections for I/O











Graphic: Lenze

| X4 - DIO, Relay | X4, X5 - AIO |
|--|---|
| <p>The diagram shows a wire with a length 'a' and a 10 mm dimension.</p> | <p>The diagram shows a wire with a length 'a' and 'b', and a 10 mm dimension.</p> |

Graphic: Lenze


5 Installation

| X4, X5 | a [mm] | b [mm] | |  [mm ²] [AWG] |
|------------|-----------|-----------|---|---|
| DIO, Relay | 90 | - |  | 0.5 ... 1.5 20 ... 16 |
| | | |  | 0.5 ... 1.0 20 ... 18 |
| AIO | 90 | 10 |  | 0.5 20 |

| X3 | a [mm] | b [mm] | |  [mm ²] [AWG] |
|----------|-----------|-----------|---|---|
| 24E, GND | 90 | - |  | 0.5 ... 1.5 20 ... 16 |
| | | |  | 0.5 ... 1.0 20 ... 18 |
| | | |  | 0.5 20 |

Graphics: Lenze


5.3.5 Connections for AS-i K2ADGFCxxx



Graphic: Lenze

5 Installation

5.3.6 Connections for CAN K2ADGFCCxxx



Graphic: Lenze

| DIP | c | b | a | Baud rate |
|-----|-----|-----|-----|-------------|
| | ON | OFF | ON | 20 kBit/s |
| | OFF | ON | ON | 50 kBit/s |
| | OFF | ON | OFF | 125 kBit/s |
| | OFF | OFF | ON | 250 kBit/s |
| | OFF | OFF | OFF | 500 kBit/s |
| | ON | ON | OFF | 800 kBit/s |
| | ON | OFF | OFF | 1000 kBit/s |


Graphic: Lenze

| DIP | Adress | | | | | | | | |
|-----|--------|-----|-----|-----|-----|-----|------|--|----------|
| | 64 | 32 | 16 | 8 | 4 | 2 | 1 | | |
| | OFF | OFF | OFF | OFF | OFF | OFF | OFF | | → C00350 |
| | OFF | OFF | OFF | OFF | OFF | OFF | ON | | → 1 |
| | OFF | ... | ... | ... | ... | ... | ... | | ... |
| OFF | ON | ON | ON | ON | ON | ON | → 63 | | |
| ON | ... | ... | ... | ... | ... | ... | ... | | |

Graphic: Lenze

5 Installation

5.3.7 Connections for PROFIBUS K2ADGFCPxxx




Graphic: Lenze

| DIP | Set | | | | | | | | Address |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|----------|
| | S | 64 | 32 | 16 | 8 | 4 | 2 | 1 | |
| | OFF | ... | ... | ... | ... | ... | ... | ... | → Master |
| | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | → C13899 |
| | ON | OFF | OFF | OFF | OFF | OFF | OFF | ON | → 1 |
| | ON | ... | ... | ... | ... | ... | ... | ... | ... |
| | ON | ON | ON | ON | ON | ON | ON | OFF | → 126 |

| | SET | 64 | 32 | 16 | 8 | 4 | 2 | 1 | ADDRESS |
|-----|-----|----|----|----|---|---|---|---|---------|
| ON | ↑ | ↑ | ↑ | ↑ | ↑ | ↑ | ↑ | ↑ | ↑ |
| OFF | ↓ | ↓ | ↓ | ↓ | ↓ | ↓ | ↓ | ↓ | ↓ |

Graphic: Lenze


5.3.8 Connections for PROFINET K2ADGFCRxxx



Graphic: Lenze


5 Installation

5.3.9 Connections for ETHERNET/IP K2ADGFCGxxx



Graphic: Lenze

5.3.10 Connections for EtherCAT K2ADGFCTxxx



Graphic: Lenze

5 Installation

5.3.11 Connections for standard I/O

5.3.11.1 Type 1

| | Pin No. | Description |
|--|---------|-------------|
| | 1 | AU/AI |
| | 2 | RFR |
| | 3 | DI1 |
| | 4 | DI2 |
| | 5 | +24V |
| | 6 | AR |
| | 7 | GND |
| | 8 | DO1 |

5.3.11.2 Type 2

| | | |
|--|---|-----|
| | 1 | NO |
| | 2 | |
| | 3 | |
| | 4 | COM |

| | | |
|--|---|-------|
| | 1 | +24V |
| | 2 | GND |
| | 3 | AR |
| | 4 | AU/AI |

| | | |
|--|---|------|
| | 1 | RFR |
| | 2 | +24V |
| | 3 | DI1 |
| | 4 | DI2 |
| | 5 | DI3 |
| | 6 | DO1 |
| | 7 | GND |
| | 8 | DI4 |

5.3.11.3 Type 3


| | | |
|--|---|-----|
| | 1 | RFR |
| | 2 | 24+ |
| | 3 | DI1 |
| | 4 | DI2 |
| | 5 | DI3 |
| | 6 | DO1 |
| | 7 | GND |
| | 8 | DI4 |

5.3.12 Connection for the safety option


| | | |
|--|---|------|
| | 1 | SIA |
| | 2 | SIB |
| | 3 | DO |
| | 4 | +24V |
| | 5 | GI |

5 Installation


5.3.13 Wiring diagram for Standard I/O



5.3.14 Wiring diagram for AS-i, CAN, PROFIBUS, PROFINET, EtherNet/IP, EtherCAT



5.3.15 Wiring diagram for Safety + (AS-i, CAN, PROFIBUS, PROFINET, EtherNet/IP, EtherCAT)




Graphics: Lenze

1) = alternativ


5 Installation





5.3.16 Wiring diagram for the safety option



Graphic: Lenze

X61



| X61 | a [mm] | |  [mm ²] [AWG] |
|--------|--------|---|--|
| Safety | 55 |  | 0.5 ... 1.5 20 ... 16 |
| | |  | 0.5 ... 1.0 20 ... 18 |
| | |  | 0.5 20 |

Graphics: Lenze


5.4 Measures when drive is used in IT systems

If the drive is mounted within an IT system, internal filters must be separated from the PE conductor. How to proceed:

1. If the controller has already been mounted: switch off mains voltage!
2. Make IT screw accessible.
 - Devices up to 3 kW: unscrew small cap on the top.
 - Devices from 4 kW: remove small cover on the top.
3. Unscrew and remove the screw(s).
4. Screw the cap on or fit the cover.

5 Installation


IT system



Graphic: Lenze

5.5 Settings


Setting elements 0.37 ... 3.0 kW



Graphic: Lenze

5 Installation

Adjustment Elements 4.0 ... 7.5 kW



Graphic: Lenze

| | Description |
|-----|---|
| P1 | „Top cover: speed ...%“ adjustment |
| X70 | Connection for USB diagnostic adapter or hand-held terminal |
| A | LED status indicator |

Possible settings with P1

Potentiometer P1 can be accessed after the cover has been removed. In order to ensure the degree of protection of the controller, the cover has to be screwed in again after the settings have been made. During operation, P1 can be used to steplessly set the motor speed in percent of the rated speed in C00011 if no JOG fixed setpoint P2 is active via DI1.

| P1 Description | Setting | | |
|--|---------|-----|-----|
| | 0 | ... | 9 |
| Motor speed in percent of the rated speed C00011 | 0 | ... | 100 |

6 Commissioning

This quick set-up guide only provides a rough outline of the procedures. Please refer to the full instructions for the model if you require answers over and above this.

Download the reference manual from: www.bauergears.com/downloads/etak20-software

6.1 Preconditions for initial switch-on

Further information can be found under: www.bauergears.com/downloads/etak20-software

Preconditions for initial switch-on

- ▶ The wiring unit is mounted and wired according to the instructions,
 - directly on a motor clamping flange or
 - with the wall adapter on a suitable surface near the motor.
- ▶ Connections with the mains, motor, holding brakes, etc. have been established.
- ▶ The communication unit has been mounted and wired according to the scheduled application.
 - Input and output signals
 - Safe input
 - Fieldbus(depending on the version, only available optionally)

Assign the digital inputs so that your application can be displayed by one of the preconfigured control modes (C00007) for terminal control:

| Assignment of the digital terminals | | | | | |
|-------------------------------------|---------|---------|--------|----------|------------|
| Control mode | DI1 | DI2 | DI3 | DI4 | DI5 |
| Terminals 0 | JOG 1/3 | JOG 2/3 | DCB | Cw/Ccw | BrkRelease |
| Terminals 2 | JOG 1/3 | JOG 2/3 | QSP | Cw/Ccw | BrkRelease |
| Terminals 11 | Cw/Ccw | DCB | MPotUp | MPotDown | BrkRelease |
| Terminals 16 | JOG 1/3 | JOG 2/3 | Cw/QSP | Ccw/QSP | BrkRelease |

| Abbreviations used: | |
|---------------------|---|
| JOG | Selection of fixed setpoints 1 ... 3 parameterised in C00039/1...3 |
| DCB | Manual DC-injection braking |
| Cw/Ccw | CW/CCW rotation |
| QSP | Quick stop |
| MPotUp | Motor potentiometer: Increase speed |
| MPotDow | Motor potentiometer: Reduce speed |
| Cw/QSP | Fail-safe selection of the direction of rotation in connection with quick stop |
| Ccw/QSP | |
| BrkRelease | Release holding brake manually <ul style="list-style-type: none">• In the standard setting, the brake control is switched off (not active). → Set operating mode in C02580. |

6 Commissioning

- ▶ The drive unit has been mounted and bolted on.
- ▶ Apply the available control functions wisely, e.g.
 - Inhibit controller release
 - Set the speed setting to minimum
 - Enable the safety device
- ▶ The use of a braking resistor has been examined.
 - It is recommended that a braking resistor always be used for units K2A400 ... 750 (4 ... 7.5 kW) when there are dynamic loads or difficult control ratios.



Danger!

Serious hazard potential during commissioning
Adjustments errors may result in unintended and hazardous movements in motors and equipment.

Possible consequences:

- ▶ Damage to property
- ▶ Injury to persons

Protective measures:

- ▶ Vacate the hazardous area
- ▶ Follow safety regulations and maintain safety distances

Depending on the bus system of the communication unit, statuses are indicated by means of an LED display. Detailed information can be found in the communication manual for the bus system used.

| LED | | 1 (green) | 2 (green) | 3 (red) | 4 (red) |
|-----|--------------|--------------------|--------------------------|-----------------------|--------------------------|
| | PROFIBUS | BUS STATE | MODULE STATE | BUS ERROR | MODULE ERROR |
| | AS-i | SLAVE 1 READY | SLAVE 2 READY | SLAVE 1 ERROR | SLAVE 2 ERROR |
| | EtherCAT | RUN | LINK/ACTIVITY | ERROR | LINK/ACTIVITY (green) |
| | PROFINET | BUS READY | LINK/ACTIVITY 1 (yellow) | BUS ERROR | LINK/ACTIVITY 2 (yellow) |
| | EtherNet/ IP | MODULE STATE (red) | | NETWORK STATE (green) | |

Graphic: Lenze

6 Commissioning

6.2 Parameter setting

Parameterisation serves to adjust the controller optimally to different application requirements.

Parameterisation using a PC and „Engineer“

- ▶ Engineering software for cross-device parameterisation, configuration and diagnostics for individual components (such as, e.g. drive control systems, industrial PCs, motors, or I/O systems) as well as machine control units
- ▶ Possible to work offline
 - Requires software and USB diagnostic adapter

Parameterisation using a PC and „Easy Starter“

- ▶ Simple online diagnostics, parameterisation and commissioning of the drive control system
 - Requires software and USB diagnostic adapter

Parameterisation using a hand-held terminal/keypad



- ▶ Adjusting specific parameters by an expert user
 - Requires a hand-held terminal suitable for EtaK2.0

Tip!

The „EASY Starter“ and „Engineer StateLevel“ engineering tools are available free of charge on the internet: www.bauergears.com/downloads/etak20-software

The USB diagnostic adapter, for example, can be used for communication between a PC and the drive control unit.

6 Commissioning

| Version | Features |
|---|--|
|  <p>Diagnosis terminal X400</p> | <p>Keypad X400 in a robust housing, also suitable for installation into the control cabinet door.</p> <ul style="list-style-type: none">• Supports hot plugging• Graphic display with plain texts• Backlighting• Easy user guidance• 4 navigation keys, 2 context-sensitive keys• Adjustable RUN/STOP function• Incl. 2.5 m cable• Enclosure IP20; in case of front installation in control cabinet IP65• Can be used for L-force Inverter Drives 8400 and Servo Drives 9400 |
|  <p>USB diagnostic adapter</p> | <p>For electrical isolation of your PC and the controller</p> <ul style="list-style-type: none">• Supports hot plugging• Diagnostic LED for data transfer display• plug and play• Input-side voltage supply via USB connection from PC• Output-side voltage supply via the diagnostic interface of the controller• Connecting cables can be selected in various lengths: |

Photos: Bauer, Lenze



Note!


Save parameter settings safe against mains failure

In order to prevent parameter settings carried out in the device from being lost by mains switching, you have to explicitly save the parameter set with mains failure protection in the device.

6.3 Change parameter settings with PC and easy starter software

The USB diagnostic adapter, for instance, can be used for the communication between the PC (including the »EASY Starter« or »Engineer« software) and the controller (see the following illustration). The USB diagnostic adapter is the connection between the PC (free USB port) and the controller (diagnostic interface).

6 Commissioning



Photos: Bauer, Lenze

The "all parameters" tab in the »EASY Starter« and the »Engineer« provides a quick access to all parameters of the controller.

The given categories and subcategories correspond 1:1 to the menus and submenus of the keypad:

The screenshot shows a software interface for parameter management. On the left is a tree view with categories and subcategories. On the right is a table of parameters. A legend at the bottom left explains the icons used in the tree view.

| | C... | S | Name | Wert | Einh... |
|--|------|---|--------------------------|---------------------------------|---------|
| | 2 | 1 | Lenze-Einstellung laden | Aus / Fertig | |
| | 7 | 0 | Steuemodus | Klemmen 0: Jog1; Jog2; DCB; R/L | |
| | 11 | 0 | Appl.: Bezugsdrehzahl | 1500 | min-1 |
| | 12 | 0 | Hochlaufzeit Hauptsollw. | 2,0 | s |
| | 13 | 0 | Ablaufzeit Hauptsollw. | 2,0 | s |
| | 15 | 0 | VFC: U/f-Eckfrequenz | 50,0 | Hz |
| | 16 | 0 | VFC: Umin-Anhebung | 0,0 | % |
| | 22 | 0 | Imax motorisch | 47,00 | A |
| | 23 | 0 | Umax Bemessungsdrehzahl | 1460 | min-1 |

A Kategorie
B Unterkategorien

Moreover, the »Engineer« provides a commissioning interface on the **Application parameters** tab where you can commission the application in a few steps.

Detailed instructions for parameterising the drive are available in the reference manual. This is available for download at: www.bauergears.com/downloads/etac20-software

6 Commissioning

6.4 Keypad

The keypad X401 serves to quickly and easily set parameters and display current actual values and device states by means of the corresponding display parameters. For this purpose, the keypad must be plugged onto the diagnostic interface on the top of the device.



Danger!

Uncontrolled motor movement possible

In general, changing a parameter causes an immediate response in the controller.

Possible consequences:

- ▶ This may lead to undesirable behaviour on the motor shaft if the controller has been enabled.

Protective measures:

- ▶ Make changes in small steps and wait for response.
- ▶ Certain device commands or settings which may cause critical states of drive behaviour constitute exceptions. Such parameter changes are only possible if the controller is inhibited. Otherwise, a corresponding error message will be issued.




Note!

The keypad can also be inserted/removed during operation.










Further information on the keypad can be found in the operating instructions supplied with the keypad.

6.4.1 Keypad display and control elements




6 Commissioning

| LCD display | | | |
|--|--|--------------------------------------|---|
| Headline | | | |
| In the menu level: Menu name In the parameter level: Parameter name | | | |
| Three-part display | | | |
| In the menu level: List of available menus In the parameter level: Code/subcode and setting or actual value | | | |
| Device status | | | |
| RDY | Controller is switched on | IMP | Pulse inhibit active |
| RUN | Controller is enabled | ISFLT | System fault active |
| CINH | Controller is inhibited | IFLT | "Fault" device status is active |
| QSP | Quick stop active | LTRB | "Trouble" device status is active |
| I_{max} | Current limit exceeded | LTQSP | "TroubleQSP" device status is active |
| M_{max} | Speed controller 1 in the limitation | WRN | A warning is indicated |
| Function - left function key | | Function - right function key | |
| EDIT | Change parameter setting (change to editing mode) | OK | Accept change in the controller (no saving with mains failure protection → SAVE) |
|  | Back to main menu | ESC | Abort (discard change) |
| CINH!!! | Parameter can only be changed when the controller is inhibited | | |
| SAVE | Save all parameter settings in the memory module safe against mains failure | | |
| Control elements | | | |
|  | Execute the function assigned to the function key (see LCD display) | | |
|  | Execute the stop function set in C00469 (setting: Inhibit controller) | | |
|  | Deactivate stop function again (setting: Enable controller again) | | |
|  | In the menu level: Select menu/submenu In the parameter level: Select parameter In the editing mode: Change marked digits or select list entry | | |
|  | In the menu level: Select submenu/change to parameter level In the editing mode: Cursor to the right | | |
|  | In the menu level: One menu level higher (if available) In the parameter level: Back to the menu level In the editing mode: Cursor to the left | | |

6 Commissioning

6.4.2 General operation

1. Use the \diamond/\diamond navigation keys to select the desired menu.
 - Use the \diamond/\diamond navigation keys to reach a higher/lower menu level.
 - Use the  function key to return to the main menu.
2. Use the \diamond/\diamond navigation keys to select the parameter to be set within a submenu.
3. Use the **EDIT** function key to switch over to the editing mode.
4. Use the navigation keys to set the desired value.
 - Use the \diamond/\diamond navigation keys to move the cursor to the right/left.
 - Use the \diamond/\diamond navigation keys to change the selected number.
5. Use the **OK** function key to accept the change and to leave the editing mode.
 - Use the **ESC** function key to leave the editing mode without accepting the change.

6.4.3 Menu structure

In the keypad, the parameters are classified into various menus and submenus.

- The **USER menu** includes a selection of frequently used parameters.
- The **Code list** contains all parameters.
- The **Go to param** function enables you to reach the corresponding parameter directly.
- The **Logbook** logs all errors and their chronological history.
- The **Diagnostics** menu contains diagnostic/display parameters for displaying device-internal process factors, current actual values and status messages

6.4.4 Overview of the commissioning steps with keypad



Note!

The following can be used at the diagnostic interface X70:

- ▶ Diagnosis terminal X401 (EZAEBK2003)
 - The described settings with the keypad X401 can also be carried out with the diagnosis terminal X401.
- ▶ USB diagnostic adapter (E94AZCUS)

Keypad control

Only some parameters must be adapted for the drive. Then the drive application can be controlled immediately in the preset control mode "Terminals 0" via the digital and analogue inputs at the controller. Alternatively, the keypad can be used for defining the required setpoints and control signals in the "Keypad" control mode.

6 Commissioning


Commissioning steps

1. Wiring of power terminals.
 - Make use of the mounting instructions supplied with the controller to wire the power terminals according to the requirements of your device.
2. Wiring of control terminals.
 - The preconfigured I/O connection can be changed via configuration parameters. See chapter "User-defined terminal assignment".
 - Assignment in the preset control mode "Terminals 0":

| Terminal | Function | | Info |
|----------|--------------------|-------|--|
| A1U | Setpoint selection | | 10 V \equiv 1500 min-1 (with 4-pole motor) general: 10 V \equiv 100 % reference speed (C00011) |
| DI1 | JOG 1 | JOG 3 | Selection of fixed setpoints 1 ... 3 <ul style="list-style-type: none"> • If both inputs are on LOW level, the setpoint selection via the analogue input A1U is active. |
| DI2 | JOG 2 | | |
| DI3 | DCB | | Manual DC-injection braking (DCB) <ul style="list-style-type: none"> • For HIGH-active inputs, DC-injection braking is active as long as DI3 is at HIGH level. • After the hold time (C00107) has expired, the controller sets the pulse inhibit (CINH). DC-injection braking (\blacktriangleright 110) |
| DI4 | R/L | | LOW level: CW rotation HIGH level: CCW rotation |
| DI5 | Holding brake | | Open/close holding brake <ul style="list-style-type: none"> • Braking modes C02580 |

3. If required, carry out communication settings via the DIP switch on the Communication Unit for fieldbus communication. If required, carry out communication settings via the DIP switch on the Communication Unit for fieldbus communication. The communication settings depend on the fieldbus used.
4. Fasten the controller by means of the 4 screws.
5. Switch on voltage supply of the controller.
6. Connect keypad.
 - Remove the cover of the diagnostic interface on the top of the device and connect the keypad to the diagnostic interface.
 - After attaching the keypad or switching on the controller with keypad attached, the connection between keypad and controller is established. The process is completed when the code C00051 appears in the display.

6 Commissioning







| Keypad display | Action |
|--|---|
| MCTRL: Act speed val. C00051 0 rpm | Use left function key  to change to main menu. |

7. Load factory setting to controller
 - For this purpose, the device command "Load setting" is available which can be executed via code C00002/1 with the keypad:



Note!

When the factory settings are loaded, changed values are overwritten. Default settings for a specific motor, e.g. for a Drive Package, would be reset with "Load factory settings".

| Keypad display | Action |
|--|---|
| EtaK2.0 Logbook Quick commissioning | A Use navigation key  to select the "Quick commissioning" menu in the main menu. B Use navigation key  to change to the "Quick commissioning" menu. |
| Part1 Quick commissioning Terminals Keypad | Use navigation key  to change to the "Terminals" menu. |
| Load factory setting C00002/1 | A Use the left function key  to change to the editing mode for C00002/1. B Use navigation key  to select the "1: On/Start" entry in the selection list. C Use the right function key  to accept the executed change and quit the editing mode. - The load process may take a couple of seconds. |

8. Enable controller: Set RFR to HIGH potential.
9. Select speed:
 - In the "Terminals 0" by selecting a voltage at the analogue input or by selecting a fixed setpoint via the digital inputs DI1/DI2.
 - In the "Keypad" control mode, the main speed setpoint and the control signals are selected via the following parameters which are available in the "Quick commissioning → Keypad" menu level:

6 Commissioning

| Parameter | Name | Info | Standard-Setting | |
|-----------|-----------------|---|------------------|------|
| | | | Value | Unit |
| C00728/3 | nMainSetValue_a | Main setpoint for the application 100 % \equiv reference speed (C00011) | 0.00 | % |
| C00727/3 | bSetSpeedCcw | Change of direction of rotation "0": CW rotation "1": CCW rotation | 0 | |
| C00727/4 | bJogSpeed1 | Selection of fixed setpoint 1 "0": Main setpoint (C00728/3) active. "1": Fixed setpoint 1 (C00039/1) active | 0 | |

10. Save parameter settings with function key **SAVE** against mains failure in the memory module.

Tip!

Recommendations for the following application cases:

- ▶ If the controller and motor differ greatly from each other in terms of performance: Set the I_{max} limit (in motor mode) in C00022 to double the rated motor current.
- ▶ If a higher starting torque is required: In idle state of the motor, set the V_{min} boost in C00016 in such a way that the rated motor current flows at a field frequency of $f = 3$ Hz (display in C00058).
- ▶ For noise optimisation: As switching frequency in C00018, set the selection "3: 16 kHz var./drive-optimised".
- ▶ If a high torque is to be available at low speed and without a feedback: Select the "vector control (SLVC)" mode in C00006 as motor control.



6 Commissioning

6.5 Commissioning

Proceed step by step:

- ▶ Switch on the mains
- ▶ Observe status display
 - After a short initialisation time, the display must be blinking green.
- ▶ Deactivate requirements of the safety function
- ▶ Set controller enable
 - After the set starting time, the motor must rotate with the set speed.
- ▶ First check of the expected behaviour:
 - Direction of rotation?
 - Starting time?
 - Speed?
 - Speed control?
- ▶ Check of optional control functions:
 - Does the analogue setpoint selection work?
 - Do the digital control signals, e.g. limit switches, work?
 - Does the connected motor holding brake work?
 - Does the change of direction of rotation work?
 - Does the requirement of the safety function work?
 - Do the control signals over fieldbus work?
- ▶ Switch off drive
 - Reduce speed
 - Inhibit controller enable
 - Switch off mains

An LED display will indicate states, depending on the bus system for the communication unit. The communications manual for the bus system used will include detailed information.

6 Commissioning

6.5.1 User menu

The usermenu can be freely configured in C00517 and contains the following parameters in the standard setting:






| Parameter | Name | Info | Standard-Setting | |
|-----------|-----------------------------------|---|------------------|------|
| | | | Value | Unit |
| C00002/19 | Device command: Reset error | After resetting the current error, further errors may be pending which must be reset as well. Details of the current error are displayed in C00166. | 0 | - |
| C00007 | Controlmode | Selection of how the application is to be controlled. | 10 | - |
| C00011 | Appl.: Reference speed | Setting the reference speed | 1500 | rpm |
| C00012 | Accel. time -main setpoint. | FB L_NSet_1: Acceleration time of the ramp generator for the main speed setpoint | 2.0 | s |
| C00013 | Decel. time -main setpoint | FB L_NSet_1: Deceleration time of the ramp generator for the main speed setpoint | 2.0 | s |
| C00016 | VFC: Vmin boost | Boost of the V/f voltage characteristic within the range of low speed or frequency values for the VFCplusmotor control. | 2.6 | % |
| C00022 | Ilmax in motormode | Maximum current in motor mode for all motor control modes | 5.8 | A |
| C00039/1 | Fixed setpoint 1 (L_NSet_1 n-Fix) | FB L_NSet_1: Fixed speed setpoints (JOG values) for the setpoint generator Fixed setpoint 1 | 40 | % |
| C00039/2 | Fixed setpoint 2 | Fixed setpoint 2 | 60 | % |
| C00105 | Deceleration time - quick stop | The set deceleration time determines the ramp slope at quick stop | 5.0 | s |
| C00120 | Motor overload threshold (I2xt) | Operating threshold for the errormessage "OC6: Motor overload (I2xt)" | 100 | % |
| C00129 | Value brake resistor | Resistance value of the connected brake resistor | 220 | Ω |
| C00165 | Error information | Display of the error numbers divided into sectors in the case of an error | - | - |
| C02580 | Holding brake: Operating mode | Selection of the operating mode for holding brake control | 0: Off | |

7 Troubleshooting

7.1 Drive diagnostics via the integrated display

On the top side of the Drive Unit, a green/red LED display indicates the respective operating status of the controller. The LED shines brightly through the transparent cap.

| LED status display | | |
|---|----------------------------------|-------------------|
| Description | green | red |
| Mains off | off | off |
| Switch-on phase (initialisation) (shining yellow) | on | on |
| Operation or motor data identification | on | off |
| Controller inhibited (RFR) | blinking | |
| Safety function active (Safe torque off) | flashing | |
| Controller is ready (initialisation completed) | flashing twice | |
| Operation with warning active | on blinking flashing twice | flashes every 3 s |
| Quick switch-off active | on | flashing |
| System error | off | on |
| Error | | blinking |
| Message is active | | flashing |

| | |
|---|---|
|  | LED flashes once approx. every 3 seconds (slow flash) |
|  | LED flashes once approx. every 1.25 seconds (flash) |
|  | LED flashes twice approx. every 1.25 seconds (double flash) |
|  | LED blinks every second |
|  | LED is permanently on |

7 Troubleshooting

7.2 Diagnostic codes

In addition to the keypad, also use the LEDs on the front of the controller for drive diagnostics:

- Two LEDs indicate the device status (DRIVE READY and DRIVE ERROR)
- Two LEDs indicate the bus status (CAN-RUN and CAN-ERROR)

The LEDs for the bus status are less important during quick commissioning.



Tip!

The handling of the keypad X401 or the diagnosis terminal X401 is described in the operating instructions. The instructions are supplied with the keypad and are also included in electronic form on the product CD "L-force Inverter Drives 8400".

Bauer does not make any representations, warranties or guarantees, expressed or implied, as to the accuracy or completeness of this manual or any statements, technical information and recommendations contained herein, or in any other documentation supplied by Bauer in connection with the use of the geared motor or gear unit (the "Product"). Before using the Product you should determine its suitability for your intended use. You bear all risk in connection with the use of the Product. You are reminded that all warranties as to merchantability and fitness for purpose are excluded from the contract under which the Product and this manual have been supplied to you. Bauer's only obligation in this respect is, at its option, to repair or replace any product proven to be defective. Neither Bauer nor any of its affiliates or any of their respective directors, officers, employees or agents shall be liable in contract, tort or in any other manner whatsoever to any person for any direct or indirect loss, damage, injury, liability, cost or expense of any nature (whether loss of profit or otherwise), including without limitation incidental, special, direct or consequential damages arising out of or in connection with the use of this manual.

Photos/Graphics: Bauer-Archive, PHOENIX CONTACT GmbH & Co. KG, Lenze GmbH

Bauer Gear Motor GmbH

Eberhard-Bauer-Straße 37

73734 Esslingen

Germany

Tel.: +49 711 3518-0

Fax: +49 711 3518-381

www.bauergears.com

