

POR SERIES Pneumatic Overload Release Clutches

Installation and Operation

P-3030-BG

POR Series
Model H2000



 **Boston**[®]
Gear

An **Altra Industrial Motion** Company

Contents

| | |
|---|----|
| I. Operating Principle..... | 2 |
| II. Mounting Adapters and Sprockets or Sheaves to Clutch..... | 3 |
| III. Locating and Mounting Clutch & Couplings to Shaft | 5 |
| IV. Limit Switches..... | 8 |
| V. Torque Adjustment | 8 |
| VI. General Maintenance | 9 |
| Torque Curves | 10 |
| VII. General Disassembly | 11 |
| VIII. General Assembly..... | 12 |
| Basic Catalog Numbers | 14 |
| Exploded View Drawing | 15 |

I. Operating Principle

The POR Series, Model H2000 is a pneumatic, ball detent style overload release clutch. It has been designed to provide accurate and dependable torque disconnect protection for mechanical power transmission equipment. Torque is transmitted through the clutch in one of two paths. Refer to Figure 1.




Figure 1

Torque transmission between the balls and detent plate is the key to the disengagement of the clutch. The balls are forced into the pockets of the detent plate by an axial load generated by an air cylinder. This axial load determines the torque capacity of the clutch. Increasing or decreasing the air pressure provides a means for remotely controlled precision "in-flight" torque adjustment. When a torque overload condition occurs, the balls roll out of the pockets and freewheel much as a ball thrust bearing. This rolling action increases the efficiency in which the clutch operates and reduces any fluctuation of torque setting due to frictional changes. Refer to Figure 2. The clutch has been designed with an internal valving mechanism. During an overload condition, the air is purged instantaneously from the cylinder.




Figure 2

The movement of the air cylinder during disengagement can be used to trip a limit switch and signal a torque overload condition. The drive should be shut down immediately and the source of the overload determined and cleared. The drive can then be restarted.

To engage the clutch, lower the air pressure and jog the drive until the clutch engages. Adjust the release torque by increasing the air pressure supplied to the clutch to reach the desired torque value. The clutch is now ready for normal operation.

II. Mounting Adapters and Sprockets or Sheaves to Clutch

A. Mounting to housing of basic clutch

1. Inspect mating pilots on clutch and sprocket, sheave or adapter for nicks or burrs and remove as required.
2. Position sprocket, sheave or adapter on clutch housing and align holes.
3. Attach sprocket, sheave or adapter to housing with mounting bolts and a high collar lock washer. Refer to Table 1 for recommended seating torques.

Note: Large sprockets or sheaves should be supported on the rotor of the clutch with an auxiliary bearing, i.e. sleeve, needle roller, radial ball. Refer to Figure 4.

Table 1 - Mounting Screws

| Type "B" | | | |
|----------|------------|------|----------------|
| Size | Screw Size | Qty. | Seating Torque |
| 02 | #8-32 | 6 | 49 in-lb |
| 04 | #10-24 | 6 | 64 in-lb |
| 05 | #5/16-18 | 6 | 305 in-lb |
| 06 | 3/8-16 | 6 | 545 in-lb |
| 09 | 7/16-14 | 6 | 70 ft-lb |
| 11 | 5/8-11 | 6 | 210 ft-lb |

| Type "T" | | | |
|----------|------------|------|----------------|
| Size | Screw Size | Qty. | Seating Torque |
| 02 | #8-32 | 6 | 49 in-lb |
| 04 | #8-32 | 3 | 49 in-lb |
| 05 | 1/4-20 | 3 | 150 in-lb |
| 06 | 1/4-20 | 3 | 150 in-lb |
| 09 | 3/8-16 | 3 | 545 in-lb |
| 11 | 3/8-16 | 3 | 545 in-lb |

B. Mounting to "T" adapter

1. Inspect mating pilots on adapter and sprocket or sheave for nicks or burrs and remove as required.
2. Position sprocket or sheave on adapter and align dowel pin holes.

3. Attach sprocket or sheave to adapter with mounting bolts and a high collar lock washer, refer to Table 1 for recommended seating torques.
4. Finish ream sprocket or sheave and adapter for dowel pins. These holes should be .0005 inches under the nominal pin diameter. Refer to Table 3 for pin sizes.
5. Install dowels to a point where they bottom in adapter.




Figure 3
Type B - Style F, Standard Sprocket Mounting




Figure 4
Type B - Style L, Standard Sheave Mounting




Figure 5 - Standard Mounting Hole Patterns

Table 2 - Minimum Acceptable Plate Sprocket Mounts

| Size | Type | Number of Teeth Per Pitch Size | | | | | | | Type | Number of Teeth Per Pitch Size | | | | | | |
|------|------|--------------------------------|---------------------|---------------------|---------------------|---------------------|-------------------|------------------------|------|--------------------------------|---------------------|---------------------|---------------------|---------------------|-------------------|------------------------|
| | | #25 1/4 Pitch | #35 3/8 Pitch | #40 1/2 Pitch | #50 5/8 Pitch | #60 3/4 Pitch | #80 1 Pitch | #100 1-1/4 Pitch | | #25 1/4 Pitch | #35 3/8 Pitch | #40 1/2 Pitch | #50 5/8 Pitch | #60 3/4 Pitch | #80 1 Pitch | #100 1-1/4 Pitch |
| 02 | B | 39 | 27 | 22 | - | - | - | - | T | 27 | 19 | 15 | - | - | - | - |
| 04 | B | 51 | 35 | 28 | 23 | - | - | - | T | 37 | 26 | 20 | 17 | - | - | - |
| 05 | B | 69 | 47 | 36 | 30 | 26 | - | - | T | 50 | 35 | 27 | 23 | 19 | - | - |
| 06 | B | 76 | 52 | 40 | 33 | 28 | - | - | T | 54 | 37 | 29 | 24 | 20 | 16 | 14 |
| 09 | B | 101 | 68 | 52 | 43 | 36 | 28 | 24 | T | 79 | 54 | 41 | 34 | 29 | 23 | - |
| 11 | B | 119 | 80 | 61 | 50 | 43 | 33 | 27 | T | 90 | 61 | 47 | 38 | 32 | - | - |

Note: Consult the factory for sprocket mounting requirements which are below the minimum sprocket values shown above.

Table 3 - Standard Mounting Hole Patterns

| Size | Type | Capscrews | | Depth Thread | Bolt Circle | +.000 -.002 Pilot | Type | Capscrews | | Dowel Pins | | Depth Thrd./ Pin | Bolt Circle | +.000 -.002 Pilot |
|------|------|-----------|---------|-----------------|----------------|-------------------------|------|-----------|--------|------------|------|------------------------|----------------|-------------------------|
| | | Qty. | Thread | | | | | Qty. | Thread | Qty. | Dia. | | | |
| 02 | B | 6 | #8-32 | 0.38 | 2.125 | 1.781 | T | 6 | #8-32 | - | - | 0.38 | 1.422 | 1.094 |
| 04 | B | 6 | #10-24 | 0.50 | 3.062 | 2.688 | T | 3 | #8-32 | 3 | 3/16 | 0.38 | 2.250 | 1.922 |
| 05 | B | 6 | 5/16-18 | 0.75 | 4.250 | 3.625 | T | 3 | 1/4-20 | 3 | 1/4 | 0.50 | 3.219 | 2.750 |
| 06 | B | 6 | 3/8-16 | 0.81 | 4.750 | 4.000 | T | 3 | 1/4-20 | 3 | 1/4 | 0.50 | 3.406 | 2.938 |
| 09 | B | 6 | 7/16-14 | 0.88 | 6.625 | 5.750 | T | 3 | 3/8-16 | 3 | 3/8 | 0.75 | 5.094 | 4.344 |
| 11 | B | 6 | 5/8-11 | 1.00 | 7.750 | 6.500 | T | 3 | 3/8-16 | 3 | 1/2 | 0.75 | 5.938 | 5.188 |

Note: 1. Mounting bolts must be minimum 160,000 PSI tensile, Rc 36-43.
 2. Dowel pins must be minimum 150,000 PSI Shear, Rc 50-58 core hardness.
 3. All Mounting holes are equally spaced.

III. Locating and Mounting Clutch and Couplings to Shaft

A. Location

The clutch should always be located as close as possible to the source of an overload condition. Figures 6 through 9 indicate both preferred and not preferred locations for mounting a POR Series, H2000 pneumatic overload release clutch.

Note: Clutch mounted sprockets, etc. and couplings should be positioned as close to a supporting bearing as possible to minimize overhung loads. A minimum shaft engagement of 1-1/2 times the shaft diameter is recommended for clutch and coupling flange installation.

1. Direct Drives

- a. Figure 6 shows the **preferred** location for mounting in a direct drive application. The clutch is mounted on the low speed side of the reducer, and transmits power from its housing, through its rotor to the driven shaft.
- b. Locating the clutch as shown in Figure 7 is **not preferred**. Here, the clutch is mounted on the high-speed side of the reducer. Generally, mounting in this manner requires the clutch to be hypersensitive to perform satisfactorily.

2. Indirect Drives

- a. Either location of the clutch shown in Figure 8 is **preferred** in indirect drive applications.
- b. The mounting location in Figure 9 is **not preferred** for the same reasons as those for Figure 7. Always consult the factory when a mounting of this type seems necessary.

B. Mounting Basic Clutch

1. Inspect shaft and key for any nicks or burrs and remove as required.
2. Loosen clamp collar on clutch.
3. Position shaft key and slide clutch onto shaft.

4. Align sprocket or sheave mounted to clutch with mating sprocket or sheave in drivetrain. Refer to installation and alignment instructions furnished with sprocket or sheave.
5. Secure clutch to drive shaft by tightening clamp collar. Refer to Table 4 for recommended seating torque for clamp collar screw.
6. Stabilize air cylinder to prevent it from rotating. Use one of three 1/4-20 x 3/8-deep holes in the O.D. of the cylinder. This connection must have flexibility to allow for axial movement of the cylinder during disengagement of the clutch.
7. Remove the protective cap from the air cylinder inlet. Connect a flexible air line from your control system to the air union. To compensate for any eccentricities occurring from installation, it is imperative that a flexible connection be used. **DO NOT PIPE SOLID.** Use a 45-degree elbow and pipe union on the riser, making certain there is a slight curve in the hose. Do not install hose taut. Adjust air pressure to the desired overload release point. Refer to Torque Curves on Page 10.




Figure 6




Figure 7

of the flange. Refer to Table 5 for recommended setscrew seating torques.




Figure 8




Figure 9

Table 4 - Clamp Collar Screws

| Clutch Size | Screw Size | Seating Torque |
|-------------|------------|----------------|
| 02 | 1/4-28 | 190 in-lb |
| 04 | 1/4-28 | 190 in-lb |
| 05 | 5/16-24 | 435 in-lb |
| 06 | 3/8-24 | 63 ft-lb |
| 09 | 1/2-20 | 140 ft-lb |
| 11 | 1/2-20 | 140 ft-lb |

C. Mounting Clutch with Type “C” Flexible Coupling

1. Inspect shafts and keys for any nicks or burrs and remove as required.
2. Loosen clamp collar on clutch.
3. Position shaft keys and slide clutch and coupling flange onto appropriate shafts.
4. Slide coupling flange onto coupling studs. The coupling flange and adapter should be separated by a gap of 1/8”.
5. Secure clutch to drive shaft by tightening clamp collar. Refer to Table 4 for recommended seating torque for clamp collar screw.
6. Secure coupling flange to drive shaft by tightening the two setscrews located in the hub

Table 5 - Setscrews

| Screw Size | Seating Torque | Screw Size | Seating Torque |
|------------|----------------|------------|----------------|
| #10-32 | 36 in-lb | 1/2-13 | 52 ft-lb |
| 1/4-28 | 87 in-lb | 9/16-12 | 52 ft-lb |
| 5/16-24 | 165 in-lb | 5/8-11 | 110 ft-lb |
| 3/8-24 | 290 in-lb | 3/4-10 | 200 ft-lb |
| 7/16-20 | 430 in-lb | 7/8-9 | 300 ft-lb |

Note: Retaining compound is furnished for screws 1/2” diameter and larger. Smaller screws are furnished with self-locking patch.

7. Check the parallel alignment.
 - a. Place a straightedge across the coupling flange and adapter as shown in Figure 10.
 - b. Measure the offset around the periphery of these two components without rotating the shafts.
 - c. If the difference in offset from any two points 180 degrees apart exceeds the maximum value shown in Table 6, the shafts must be realigned.

Table 6 - “C” Coupling

| Size | Maximum Allowable Misalignment | |
|------|--------------------------------|---------------|
| | Parallel - In. | Angular - In. |
| 02 | 0.012 | 0.055 |
| 04 | 0.016 | 0.074 |
| 05 | 0.027 | 0.101 |
| 06 | 0.045 | 0.117 |
| 09 | 0.045 | 0.174 |
| 11 | 0.045 | 0.226 |

8. Check angular alignment with a micrometer or caliper.
 - a. Measure from the outside of the coupling flange to the outside of the adapter around the periphery of these two components **without rotating** the shafts. Refer to Figure 11.
 - b. If the difference between any two points 180 degrees apart exceeds the maximum angular misalignment value shown in Table 6, the shafts must be realigned.

- c. If a correction is required to satisfy angular alignment requirements, then recheck the parallel alignment.
9. Stabilize air cylinder to prevent it from rotating. Use one of three 1/4-20 X 3/8-deep holes in the O.D. of the cylinder. This connection must have flexibility to allow for axial movement of the cylinder during disengagement of the clutch.
 10. Remove the protective cap from the air cylinder inlet. Connect a flexible air line from your control system to the air union. To compensate for any eccentricities occurring from installation, it is imperative that a flexible connection be used. DO NOT PIPE SOLID. Use a 45-degree elbow and pipe union on the riser, making certain there is a slight curve in the hose. Do not install hose taut. Adjust air pressure to the desired overload release point. Refer to Torque Curves on Page 10.




Figure 10 - Parallel "C" Coupling Alignment




Figure 11 - Angular "C" Coupling Alignment

D. Mounting Clutch with Type "R" - Rigid Coupling

1. Inspect mating pilots of clutch and coupling flange for nicks or burrs and remove as required.
2. Inspect shafts and keys for any nicks or burrs and remove as required.
3. Loosen clamp collar on clutch.
4. Position shaft keys and slide clutch and coupling flange onto appropriate shafts.
5. Slide coupling flange and clutch together until they contact and align mounting holes.
6. Secure clutch to drive shaft by tightening clamp collar. Refer to Table 4 for recommended seating torque for clamp collar screw.
7. Secure coupling flange to drive shaft by tightening the two setscrews located in the hub of the flange. Refer to Table 5 for recommended setscrew seating torques.
8. Check the parallel alignment.
 - a. Place a straightedge across the coupling flange and clutch as shown in Figure 12.
 - b. Measure the offset around the periphery of these two components **without rotating** the shafts.
 - c. The shafts must be aligned until no offset exists or is equal at all points around the periphery.
9. Check angular alignment.
 - a. Measure the gap around the periphery between the coupling flange and clutch **without rotating** the shafts. Refer to Figure 13.
 - b. The shafts must be aligned until no gap exists or is equal at all points around the periphery.
 - c. If a correction is required to satisfy angular alignment requirements, then recheck the parallel alignment.

Note: The “R” coupling connection is rigid and does not allow for forgiveness of parallel or angular misalignment. To eliminate unnecessary bearing loads, both shafts must be in near perfect alignment.

10. Loosen clamp collar of clutch. Attach coupling flange to clutch with mounting bolts and a high collar lock washer. Refer to Table 1 for recommended seating torques. Tighten clamp collar to secure clutch to drive shaft.
11. Stabilize air cylinder to prevent it from rotating. Use one of three 1/4-20 x 3/8-deep holes in the O.D. of the cylinder. This connection must have flexibility to allow for axial movement of the cylinder during disengagement of the clutch.
12. Remove the protective cap from the air cylinder inlet. Connect a flexible air line from your control system to the air union. To compensate for any eccentricities occurring from installation, it is imperative that a flexible connection be used. DO NOT PIPE SOLID. Use a 45-degree elbow and pipe union on the riser, making certain there is a




Figure 12 - Parallel “R” Coupling Alignment




Figure 13 - Angular “C” Coupling Alignment

slight curve in the hose. Do not install hose taut. Adjust air pressure to the desired overload release point. Refer to Torque Curves on Page 10.

IV. Limit Switches

The POR Series clutch is an automatic reset device. Because of this feature it is important that the drive be shut down immediately upon a torque overload condition. The switch should be able to operate within the disengagement travel of the clutch. Upon an overload, the cylinder of the clutch will move to actuate the limit switch and shut down the drive. An oversized metallic plate provides a means for sensing movement from both ends of the clutch and the utilization of precision proximity switches.

The limit switch should be wired in its normally closed condition. The switch is used to open the circuit to the motor during a torque overload condition. The switch should be wired in parallel with the JOG button of the motor control. This will permit the drive to be started in the event the POR Series clutch has stopped with the limit switch circuit in an open state.

Figure 14 shows limit switch kits available for the POR Series clutch which are compatible with the POR PC. (Refer to Section VI.) Before using this switch in your circuit verify that the electrical ratings meet your requirements.

V. Torque Adjustment

The POR Series pneumatic overload release clutch provides precision “in-flight” torque control. By simply varying the air pressure supply, you can remotely adjust the release torque of the clutch while in operation.

The torque curves on page 10 can be used to approximate the air pressure required to yield a desired torque setting.

Example:

- Clutch Size – 05
- Torque Setting – 3,600 in.-lb.
- Air Pressure by Curve – 60 psi
- Air Pressure by Equation – 60.3 psi

For applications requiring a precise release torque, the release torque setting of the clutch should be tested as shown in Figure 15. Verification of the release torque several times in both clockwise and counterclockwise directions is recommended.

| Size | A | B | C | D | E | Unit Switch Kit No. |
|------|-------|-------|------|------|------|---------------------|
| 02 | 3.88 | 5.81 | .060 | 1.63 | 1.50 | 711700-001 |
| 04 | 4.75 | 7.25 | .078 | 2.25 | 1.73 | 711700-001 |
| 05 | 6.63 | 8.88 | .110 | 2.60 | 2.63 | 711701-001 |
| 06 | 7.75 | 10.12 | .128 | 2.82 | 3.06 | 711701-001 |
| 09 | 10.00 | 12.50 | .165 | 3.60 | 4.00 | 711702-001 |
| 11 | 12.25 | 14.62 | .183 | 3.95 | 5.00 | 711702-001 |

| Circuit | Electrical Rating | | |
|--|---------------------|------|-------|
| | Silver Contacts | | |
| 1NO - 1NC Red Black Green Blue | Volts | Make | Break |
| | 125 AC | 7.2A | 1.2A |
| | 250 AC | 1.2A | 0.2A |
| | 5.1 Amps Continuous | | |
| | 3A (Res.) at 28 VDC | | |





Figure 14 - Limit Switches




Figure 15 - Torque Verification







VI. General Maintenance

A. Lubrication

The POR Series clutch is pre-lubricated at the factory and is also equipped with lube fittings for scheduled lubrication. The size 02 is lubricated with a light oil and sizes 04 through 11 with a Bentone type, NLGI grade 0 grease. The lubrication schedule should be in accordance with good operating practices for the equipment on which the clutch is mounted.

B. Annual Inspection

The POR Series overload release clutch is constructed of heavy-duty materials. Under reasonably clean conditions the unit will operate with a minimum of maintenance. A scheduled annual inspection of seals, bearings and other internal components is suggested. However, the actual frequency should be in accordance with good operating practices for the equipment on which the clutch is installed.



Torque Curves

Note: In accordance with our established policy to constantly improve our products, the specifications contained herein are subject to change without notice.

CAUTION Rotating equipment is potentially dangerous and could cause injury or damage if not properly protected. Follow all applicable codes and regulations.

VII. General Disassembly

A. Cover, cylinder and miscellaneous internal components

1. Loosen capscrew from clamp collar and remove collar.
2. Remove the air muffler from the face of the piston.
3. Remove the external snap ring, retaining the piston bearing to the rotor.
4. Press off the cylinder half from the rotor as shown in Figure 13.
5. Remove the piston from the inside of the cylinder.
6. Remove the valve from the cylinder by removing the valve screw.
7. Lift cover assembly off of the housing and rotor.
8. Lift thrust bearings, washers and thrust plate from rotor.
9. Use a magnet to remove steel balls from rotor flange.




Figure 16

B. Housing and miscellaneous internal components

1. Remove any adapters, couplings, sprockets or sheaves from the housing.
2. Remove ring, retaining rear spacer to rotor. On clutch sizes 09 and 11 there are two capscrews which must be removed from rear spacer.
3. Insert capscrews in threaded holes of rotor flange. Use these screws to push rear spacer off rotor. Screws must be turned evenly and progressively to avoid binding.

Because of the extended length of the rotor on a Style "L" clutch, it will be necessary to press the rotor through the housing with an arbor. Use the push off holes in the rotor flange to separate the detent plate from the rotor flange. See Table 7 for push off hole sizes. Support the clutch by the detent plate as shown in Figure 16 and push the rotor through the housing.

4. Remove thrust bearing and washers from housing.
5. Separate detent plate from housing.

Table 7 - Push Off Holes

| Size | Qty. | Hole Size |
|------|------|-----------|
| 02 | 3 | #6-32 |
| 04 | 4 | 1/4-28 |
| 05 | 4 | 1/4-28 |
| 06 | 4 | 1/4-28 |
| 09 | 4 | 3/8-24 |
| 11 | 4 | 3/8-24 |




Figure 17

VIII. General Assembly

A. Housing and miscellaneous internal components

1. Grease pack O-ring groove in housing and insert O-ring seal.
2. Paint pocket side of detent surface with grease on all sizes except 02. The detent surface of the 02 housing should be brushed with a light oil.
3. Slip housing onto rotor.
4. Grease coat thrust bearing and washers. Sandwich bearing between washers and slip into cavity of housing.
5. Press rear spacer onto rotor until the snap ring groove in rotor is cleared and install snap ring into groove.
6. On clutch sizes 09 and 11, the tabs of the snap ring must be oriented between the two tapped holes in rear spacer. Install spacer as shown in Figure 18.

B. Cover and miscellaneous internal components

1. Grease pack groove in cover and insert quad seal.
2. Paint steel balls with grease on all clutch sizes except 02, these should be dipped in a light oil. Align ball holes of rotor flange with pockets in detent plate. Insert steel balls into holes of rotor flange.
3. Place the thrust plate on the rotor.
4. Grease coat both thrust washers.
5. Place one thrust washer on the pilot of the thrust plate and the other thrust washer on the pilot inside of the cover.
6. Grease coat thrust bearing and place it on top of the thrust washer on the thrust plate.
7. Slip the cover assembly onto rotor. The cover assembly is properly installed when the edge of the cover meets the outside edge of the counterbore of the grease fitting on the housing.





Figure 18

C. Cylinder, piston and miscellaneous internal components

1. Grease pack grooves of cylinder and install quad ring seals.
2. Install the springs into the spring pockets in the cylinder.
3. Press piston bearing into bearing pocket of the piston.
4. Install the internal snap ring into the groove of the piston.
5. Grease coat the outside diameter of the piston and outer surface of the hub of the piston.
6. Align the piston and cylinder using the dowel pin as a locator. Gently push the piston into cylinder until the piston bottoms out. If it is difficult, make sure that the inner seal is not binding. If the inner seal is binding, slowly back the piston out and adjust the seal so that the piston hub can slide through it.
7. Coat the outside diameter of the cover ball bearing with a layer of an anti-seize compound.
8. With the piston facing upward, place the piston and cylinder assembly over the rotor and press the piston and cylinder onto the rotor until the piston bearing has cleared the snap ring groove in the rotor.
9. Install the external snap ring into the groove of the rotor.

10. Apply a thin coat of grease to the O-ring of the valve body.
11. Insert the valve assembly into the counter-bored hole of the piston.
12. Apply a light grade of thread locking compound to the threads of the valve screw. Loctite Removable Threadlocker 242 or equivalent is recommended. For the size 02 apply right to the threads of the valve. Secure the valve by tightening the valve screw with a phillips head screwdriver. For a size 02 use a straight blade screwdriver. **Be sure not to over tighten the valves for it may damage the threads in the cylinder!** For the size 02 it may be necessary to adjust the valve for leakage. Make sure that the valve is bottomed out in the cylinder. Apply air to the clutch and disengage the clutch. If the valve does not bleed air upon disengagement, slowly turn the valve counterclockwise until the valve bleeds. Reset the clutch and make sure that the valve seals.
13. Install air muffler in valve hole of the piston and tighten.

POR Series Part Numbering System



Part Identification For Type B, Style F & Style L Basic Unit

| Item No. | Name | Qty. | 02 | 04 | 05 | 06 | 09 | 11 | |
|----------|----------------------|---------|------------|------------|------------|------------|------------|------------|------------|
| 1 | Clutch Assembly | Style F | - | 711600-002 | 711601-004 | 711602-005 | 711603-006 | 711604-009 | 711605-011 |
| | | Style L | - | 711606-002 | 711607-004 | 711608-005 | 711609-006 | 711610-009 | 711611-011 |
| 2 | Valve Sub-Assembly | 1 | 711692-002 | 711377-001 | 711595-001 | 711595-001 | 711595-001 | 711595-001 | |
| 3 | Cover Sub-Assembly | 1 | 711656-002 | 711657-004 | 711658-005 | 711659-006 | 711660-009 | 711661-011 | |
| 4 | Housing Sub-Assembly | 1 | 711036-602 | 711040-604 | 711044-605 | 711048-606 | 711052-609 | 711056-611 | |
| 5 | Seal Kit | 1 | 711650-002 | 711651-004 | 711652-005 | 711653-006 | 711654-009 | 711656-011 | |
| 6 | Thrust Bearing Kit | 1 | 711647-002 | 711042-604 | 711046-605 | 711050-606 | 711054-609 | 711058-611 | |
| 7 | Rotor | Style F | 1 | 731465-001 | 731439-001 | 731472-001 | 731450-001 | 731477-001 | 731482-001 |
| | | Style L | 1 | 731461-001 | 731549-001 | 731565-001 | 731447-001 | 731473-001 | 731478-001 |
| 8 | Thrust Plate | 1 | 731304-001 | 731310-001 | 731324-001 | 731317-001 | 731331-001 | 731339-001 | |
| 9 | Ball Bearing | 1 | 039273-074 | 039273-069 | 039273-070 | 039273-049 | 039273-071 | 039273-072 | |
| 10 | Rear Spacer | 1 | 731306-001 | 731312-001 | 731327-001 | 731320-001 | 731335-001 | 731343-001 | |
| 11 | Clamp Collar | Style F | 1 | 730094-028 | 730094-029 | 730094-021 | 730094-022 | 730094-025 | 730094-035 |
| | | Style L | 1 | 730094-028 | 730094-029 | 730094-030 | 730094-022 | 730094-025 | 731244-001 |
| 12 | Cylinder | 1 | 731463-001 | 731437-001 | 731470-001 | 731448-001 | 731475-001 | 731480-001 | |
| 13 | Piston | 1 | 731462-001 | 731438-001 | 731471-001 | 731449-001 | 731476-001 | 731481-001 | |
| 14 | Ball | *4 | 070071-007 | 070071-003 | 070071-008 | 070071-001 | 070071-009 | 070071-010 | |
| 15 | Snap Ring | 1 | 040682-042 | 040682-043 | 040682-025 | 040682-045 | 040682-046 | 040682-047 | |
| 16 | Cap Screw | 2 | N/A | N/A | N/A | N/A | 075519-001 | 075519-001 | |
| 17 | Snap Ring | 1** | 040682-042 | 040682-043 | 040682-050 | 040682-045 | 040682-046 | 040682-063 | |
| 18 | Snap Ring | 1 | 040682-056 | 040682-057 | 040682-058 | 040682-059 | 040682-060 | 040682-061 | |
| 19 | Air Muffler | 1 | 730338-002 | 730338-002 | 730338-004 | 730338-004 | 730338-004 | 730338-004 | |
| 20 | Dowel Pin | 1 | 023921-020 | 023921-009 | 023921-020 | 023921-020 | 023921-020 | 023921-021 | |
| 21 | Piston Spring | 3 | 034124-081 | 034124-081 | 034124-081 | 034124-081 | 034124-081 | 034124-081 | |
| 22 | Actuating Plate | 1 | 731566-001 | 731566-002 | 731566-003 | 731566-004 | 731566-005 | 731566-006 | |
| 23 | Cap Screw | 6 | 074103-001 | 074103-001 | 074103-001 | 074103-004 | 074103-010 | 074103-016 | |


* Size 02 uses only 3 balls.

** Sizes 02 and 11 use 2 snap rings.

Clutch serial number required when ordering spare parts.

Part Identification Adapters

| Name | 02 | 04 | 05 | 06 | 09 | 11 |
|--------------------------|------------|------------|------------|------------|------------|------------|
| "C" Adapter Sub-Assembly | 712037-602 | 712038-604 | 712039-605 | 712040-606 | 712041-609 | 712042-611 |
| "R" Adapter Sub-Assembly | 712043-602 | 712044-604 | 712045-605 | 712046-606 | 712047-609 | 712048-611 |
| "T" Adapter Sub-Assembly | 712031-602 | 712032-604 | 712033-605 | 712034-606 | 712035-609 | 712036-611 |



Type B - Style F, Basic Unit

Warranty

Boston Gear warrants that products manufactured or sold by it shall be free from defects in material and workmanship. Any products which shall within two (2) years of delivery, be proved to the Company's satisfaction to have been defective at the time of delivery in these respects will be replaced or repaired by the Company at its option. Freight is the responsibility of the customer. The Company's liability under this limited warranty is limited to such replacement or repair and it shall not be held liable in any form of action for direct or consequential damages to property or person. THE FOREGOING LIMITED WARRANTY IS EXPRESSLY MADE IN LIEU OF ALL OTHER WARRANTIES WHATSOEVER, EXPRESS, IMPLIED AND STATUTORY AND INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS.

No employee, agent, distributor, or other person is authorized to give additional warranties on behalf of Boston Gear, nor to assume for Boston Gear any other liability in connection with any of its products, except an officer of Boston Gear by a signed writing.



www.bostongear.com

701 Carrier Drive
Charlotte, NC 28216
704-588-5610
Fax 704-588-7181

An **Altra Industrial Motion** Company

