


Motor Series D.. / E.. / S..

English



Digital documentation

Scan the QR code to view and download more languages.



BG Сканирайте QR кода, за да видите и да изтеглите още езици.

CN 扫描二维码以查看和下载更多语言。

CZ Pro zobrazení a stažení dalších jazyků naskenujte QR kód.

DE Scannen Sie den QR-Code, um weitere Sprachen anzusehen und herunterzuladen.

DK Scan QR-koden for at se og downloade flere sprog.

EE Muude keelte nägemiseks ja alla laadimiseks skannige QR-kood.

EN Scan the QR code to view and download more languages.

ES Escanee el código QR para ver y descargar más idiomas.

FI Skanna QR-koodi nähdäksesi muut kielet ja lataaksesi sisältöä.

FR Scannez le code QR pour afficher et télécharger d'autres langues.

GR Σαρώστε τον γραμμωτό κώδικα QR, για να δείτε και να κατεβάσετε περισσότερες γλώσσες.

HR Skenirajte QR kod za pregled i preuzimanje drugih jezika.

HU További nyelvek megtekintéséhez és letöltéséhez olvassa be a QR-kódot.

IT Scansiona il codice QR per visualizzare e scaricare altre lingue.

LT Nuskaitykite QR kodą, jei norite peržiūrėti ir atsisiųsti daugiau kalbų

LV Noskenējiet QR kodu, lai skatītu un lejupielādētu citas valodas.

NL Scan de QR-code om meer talen te bekijken en te downloaden.

NO Skann QR-koden for å se og laste ned flere språk.

PL Zeskanować kod QR, aby zobaczyć i pobrać inne języki.

PT Ler o código QR para ver e descarregar mais idiomas.

RO Scanați codul QR, pentru a vizualiza și descărca și alte limbi.

RU Отсканируйте QR-код, чтобы просмотреть и загрузить другие языки.

SE Skanna QR-koden för att se och ladda ned fler språk.

SI Naskenujte QR kód, aby ste si mogli pozrieti a stiahnuť dokumentáciu v ďalších jazykoch.

SK Skenirajte QR kodo, da si ogledate in prenesete dodatne jezike.

TR Daha fazla dil görüntülemek ve indirmek için QR kodunu tarayın.

Table of contents

1	About this documentation	6
1.1	Product name	6
1.2	Validity	6
1.3	Applicable documents	6
1.4	Symbols and means of representation	7
1.4.1	Warnings	7
1.4.2	Symbols and means of representation	7
1.5	Abbreviations	8
1.6	Copyright	8
2	Safety	9
2.1	Intended use	9
2.2	Improper use	9
2.3	Personnel qualification	9
2.4	Residual risks	10
2.5	Pictograms on product	12
2.6	Personal protective equipment	12
2.7	Safety devices	12
2.8	Environmental protection and disposal	12
3	Product description	13
3.1	Product identification: motor	13
3.1.1	Rating plate/type plate	13
3.2	Type code/type designation	13
3.3	Motor type designation.....	14
3.4	Type designation of motor attachments.....	15
3.4.1	Installation positions	16
3.5	Functional description	16
3.5.1	Three-phase motor	16
3.5.2	Brakes	16
3.5.3	Encoder system	17
3.5.4	Backstop (RR, RL)	17
3.5.5	Second motor shaft end (ZW, ZV)	17
3.5.6	Rain cover above fan cover (D)	17
3.5.7	Motor heating	17
4	Included with delivery	17
5	Transport and storage	18
5.1	Goods Receiving	18
5.2	Transportation	18
5.3	Storage	19
5.3.1	Short-term storage	19
5.3.2	Long-term storage	19
6	Installation	20
6.1	Requirements for installation site	20
6.1.1	Substructure	20
6.1.2	Cooling air supply	20
6.1.3	Installation outdoors or in damp rooms	20
6.1.4	Installation of roller table drives	20
6.2	Mechanical installation	20
6.2.1	Required tools and aids	20
6.2.2	Inspections and preparatory work before installation	20
6.2.3	Drive elements.....	21
6.2.4	Motor with second shaft end	21
6.3	Installation of standard motors	22

6.4	Electrical installation	22
6.4.1	Required tools and aids	22
6.4.2	Prerequisites	23
6.4.3	Open cable entry of cast-on terminal box (D..04.. to D..11..)	24
6.4.4	Electrical connection on terminal block	25
6.4.5	Electrical connection on terminal board	26
6.4.6	Electrical connection with plug-in connection on terminal box, CleanConnect® plug, or cable version (CleanDrive)	28
6.4.7	Protective earthing	28
6.4.8	Contact protection	28
6.4.9	Electrical connection for motor protection devices	28
6.4.10	Stator standstill heating	29
6.4.11	Electrical connection for brakes	30
6.4.12	Electrical connection for external fan	31
6.4.13	Encoder electrical connection	31
6.4.14	Connection for motors with plug	32
6.4.15	Connection of rotating field magnet motors	32
7	Commissioning	32
7.1	Checks before commissioning	32
7.2	Initial commissioning	32
7.3	Commissioning after long-term storage	33
7.3.1	Motor measures	33
8	Normal operation	33
9	Malfunctions and troubleshooting	33
9.1	Motor malfunctions	33
9.2	Brake malfunctions	35
10	Repair	35
11	Maintenance	36
11.1	Maintenance schedule	36
11.2	Motor inspection and maintenance	37
11.3	Inspection and maintenance of brakes	38
11.3.1	Maintenance of brake types E003B and E004B	38
11.3.2	Maintenance of single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A	39
11.3.3	Maintenance of single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A	40
11.3.4	Maintenance of double-disc holding brakes ZS300A ... ZS500A	40
11.3.5	Maintenance of double-disc service brakes ZSX300A ... ZSX500A	41
11.4	Cleaning and maintenance	41
12	Decommissioning	41
13	Disassembly	42
14	Disposal	42
14.1	Packaging	42
14.2	Motor	42
15	Spare parts and accessories	42
16	Technical data	42
16.1	General data and conditions of use	42
16.2	Motors	43
16.2.1	General	43
16.2.2	Permanent magnet synchronous motors (PMSMs)	43

16.3	Motor attachments and accessories	43
16.3.1	External fan	43
16.3.2	Brakes	44
16.3.3	Encoder system	47
16.3.4	Backstop (RR, RL)	49
16.4	Brake maintenance	49
16.4.1	Spring-loaded brake of series E003B or E004B	49
16.4.2	Single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A	50
16.4.3	Double-disc holding brakes ZS300A ... ZS500A	50
16.4.4	Single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A	51
16.4.5	Double-disc working brakes ZSX300A ... ZSX500A	51

List of figures

Fig. 1:	mounting positions.....	16
Fig. 2:	Connection diagram for stator standstill heating via heater bands	29
Fig. 3:	MSG1.5.4801 rectifier sensor.....	31

List of tables

Tab. 1:	Tightening torques for tensioning screws	22
Tab. 2:	Connection of single-wire conductor; version with stud terminal	26
Tab. 3:	Tightening torques for electrical connection on terminal board	26
Tab. 4:	Tightening torques for terminal box screw connection	28
Tab. 5:	Electrical connection variants – properties and information	28
Tab. 6:	Brake connection options.....	30
Tab. 7:	Motor malfunctions	34
Tab. 8:	Brake malfunctions	35
Tab. 9:	Maintenance schedule	37
Tab. 10:	Schmierstofftabelle	38
Tab. 11:	Permissible ambient conditions	42
Tab. 12:	PMSM parameters.....	43
Tab. 13:	Technical data, external fans	43
Tab. 14:	Abbreviations for brake technical data	44
Tab. 15:	Technical data for spring-loaded brakes with DC release solenoid of type E003B and E004B	45
Tab. 16:	Technical data for spring-loaded holding brakes with emergency stop feature of type ES.../ZS... ..	45
Tab. 17:	Technical data for spring-loaded service brakes of type ES(X).../ZS(X).....	46
Tab. 18:	Special features – standard impulse encoders.....	47
Tab. 19:	Special features – standard absolute encoders	47
Tab. 20:	Technical data for incremental rotary encoders	47
Tab. 21:	Electrical parameters, incremental rotary encoders	47
Tab. 22:	Technical data for incremental rotary encoders	48
Tab. 23:	Abbreviations for brake maintenance.....	49
Tab. 24:	Technical data for maintenance of spring-loaded brakes of series E003B or E004B	49
Tab. 25:	Technical data for maintenance of single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A	50
Tab. 26:	Technical data for maintenance of double-disc holding brakes ZS300A ... ZS500A	50
Tab. 27:	Technical data for maintenance of single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A	51
Tab. 28:	Technical data for maintenance of double-disc service brakes ZSX300A ... ZSX500A	51

1 About this documentation

These Assembly and Operating Instructions (hereinafter referred to as “documentation”) are an integral part of the product. It is intended for persons carrying out work associated with the product and contains important information on safety and safe handling of the device. All safety instructions and work steps specified must be followed in order to work safely with the device.

- ▶ Read this document carefully before starting any work.
- ▶ Keep these Assembly and Operating Instructions in the immediate vicinity of the device, accessible to personnel at all times, and in legible condition

For purposes of better presentation, the figures in this document are not to scale and may differ from the actual version.

- ▶ Should anything be unclear, please contact Bauer Gear Motor.

You can download the complete operating instructions in digital form with larger font here:



You can find further documentation at www.bauergears.com.

1.1 Product name

Product designations mentioned in this document are trademarks of Bauer Gear Motor, some with a registered trademark ®.

1.2 Validity

This document applies to the following series:

- Motor series D../E../S..

1.3 Applicable documents

The following documents form part of these Assembly and Operating Instructions:




- Connection diagram (supplied with device)
- Manufacturer documentation of supplier components

1.4 Symbols and means of representation



1.4.1 Warnings

Warnings are used in this document to warn of situations that could cause damage to property and personal injury.

- ▶ Read and observe warning notices.
- ▶ Follow all steps marked with the warning symbol and warning word.

Safety Alert Symbol	Signal Word	Meaning
	DANGER	indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	WARNING	indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	CAUTION	indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
–	NOTICE	indicates practices not related to physical injury and which, if not avoided, could result in property damages.

1.4.2 Symbols and means of representation

Symbol	Meaning
	means "additional information"
	Symbol for an action: You must do something here. ▶ If there are several steps, follow the order given.

1.5 Abbreviations

Abbreviation	Definition	Description
AC	Alternating current	AC current
BCD	-	Output code for absolute encoder with SSI interface
CRC	-	Output format for absolute encoder with SSI interface
DC	Direct current	DC current
DP	Decentralised Periphery	PROFIBUS interface variant
ESG	Electronic fast-acting rectifier	Fast-acting rectifier
EMC	Electromagnetic compatibility	-
HL	Manual release	-
HTL	-	Output signal for incremental encoder
OK	Okay	-
IP	Ingress protection	Protection rating, indicates protection for active parts against contact, ingress of foreign bodies and water
MSG	Fast-acting rectifier with over-excitation	Fast-acting rectifier
NN	Normal-null ("standard elevation zero")	-
PMSM	Permanent magnet synchronous motor	-
PNO	Encoder profile	for absolute encoder with Profibus interface
RL	Backstop, blocking direction left	-
RR	Backstop, blocking direction right	-
SSI	Synchronous Serial Interface	SSI Synchronous Serial Interface
SSV	Shrink disc connection	-
TR	Programmable parameter	Speed output
TTL	Programmable parameter	Output signal for incremental encoder
V/R	Counting direction	For absolute encoder with SSI interface
UB	Non-ventilated	-
USIT	Gaskets	USIT rings
UVV	Accident prevention regulations	-
ZV	Shaft with square end	Second motor shaft end
ZW	Shaft with key	Second motor shaft end

1.6 Copyright

Bauer Gear Motor reserves all rights regarding this document. No part of this document may be reproduced, redistributed, modified, or otherwise utilised.

2 Safety

The safety instructions serve to prevent personal injury and material damage. They relate only to the drive unit concerned in this document.

▶ When using special options/components: Also refer to additional product-specific documents provided.

The product is part of a drive system and may only be put into operation if it has been properly determined that the machine or system can be operated safely.

▶ Operate the product only in accordance with the information in this document and with the information on the name plate.

▶ Only operate the entire unit in the mounting position specified on the name plate.



WARNING!

Failure to observe the documentation
 Serious or fatal injuries may result.

▷ Before using the product, carefully read this documentation and all other relevant documents.

The operator must ensure that all persons entrusted to work on the product have read and understood this document and that they follow the safety instructions given.

▶ Keep this document near the product in a place accessible to the operator.

2.1 Intended use

The products are three-phase motors intended exclusively for use in commercial machines and systems.

2.2 Improper use

The following is considered improper or incorrect use:

- Changes to product
- Use in potentially explosive areas

2.3 Personnel qualification

Knowledge of this documentation is a prerequisite for all persons.

▶ Only qualified personnel are permitted to perform any work with or on the product.

Person group	Required qualifications
Electrician	<ul style="list-style-type: none"> • Specific and general education and training as an electrician • At least 2 years of relevant professional experience • Knowledge of how drive units work and how to handle them • Experience using common work tools • Routine use of smartphones (e.g. videos), PC/tablet
Mechanic	<ul style="list-style-type: none"> • Specific and general training as a mechanic • At least 2 years of relevant professional experience • Knowledge of how drive units work and how to handle them • Experience using common work tools • Routine use of smartphones (e.g. videos), PC/tablet.

Qualified personnel must be familiar with and observe the IEC 60364/IEC 60664 standards as well as national occupational safety and accident prevention regulations and environmental regulations.

Bauer Gear Motor GmbH offers disassembly and assembly training at regular intervals both at its head-quarters and on site. Training content and dates can be found at www.bauergears.com/sales-and-service/gear-motor-academy/ under "Gear Motor Academy". Register for training courses online at www.bauergears.com/sales-and-service/global-service/ under "Gear Motor Academy Registration". Coordinate individual training sessions with head office.

2.4 Residual risks

Hazardous voltage

Serious or fatal injuries may result.

- ▷ Before working on electrical components of the product, ensure that there is no voltage.
- ▷ Take appropriate measures to prevent unintentional or accidental restart, such as removing fuses, assigning personnel to monitor, placing warning signs, etc.

Electric shock due to regenerative operation with permanent magnet synchronous motors (PMSM)

Serious to fatal injuries due to regenerative operation can result. When the drive is driven by the output shaft, the motor induces a voltage that is present at the motor terminals.

- ▷ Prevent the output shaft from turning, e.g. by blocking it mechanically.

Magnetic fields

Serious or fatal injuries may result.

- ▷ Persons with pacemakers and implants are prohibited from standing near the product and handling the product.

Automatic restart

Serious or fatal injuries may result from persons being drawn-in and caught.

- ▷ Before starting maintenance and repair work, make sure that the machine/system cannot be switched on again.
- ▷ During commissioning, ensure that no unauthorised persons are in the hazard zone.
- ▷ Place warning signs.
- ▷ Keep a safe distance from moving parts.

Improper assembly or disassembly

Serious to fatal injuries and property damage can result.

- ▷ Ensure that only authorised personnel are present on site.
- ▷ Only perform assembly and installation work when the machine/system is standing idle.
- ▷ Only perform work on the product when it is at a standstill and safeguarded from being inadvertently switched on, and the connection voltage is safely disconnected.
- ▷ Secure heavy components and attachments from falling.
- ▷ Ensure there is sufficient safety clearance, e.g. by using barriers as necessary.

Rotating parts

Serious or fatal injuries may result from persons being drawn-in and caught.

- ▷ Before starting maintenance and repair work, make sure that the machine/system cannot be switched on again.
- ▷ Do not work on couplings, brakes, or backstops unless they are safeguarded against a unit automatically starting up, a trolley/shuttle rolling, or a load dropping or even falling, etc.

Parts breaking loose

Parts may break loose and cause minor to moderate injury.

- ▷ Wear safety glasses during assembly and disassembly.

Hot surfaces

Serious injury from skin burns may result.

- ▷ Allow hot product surfaces to cool before touching them.
- ▷ Suitable protective gloves must be worn when working on hot product components.

Frozen surfaces

Serious injury from cold burns on skin

- ▷ Allow cold product surfaces to warm before touching them.
- ▷ Suitable protective gloves must be worn when working on frozen product components.

High noise emissions

Hearing damage may result

- ▷ Wear hearing protection.

Forces and torques when separating transmission elements

Serious or fatal injuries may result.

- ▷ Only loosen and disconnect transmission elements such as couplings, chain and belt drives, etc. if no force or torque is acting on the output shaft.

Non-approved spare parts

Serious to fatal injuries and material damage from drive failure, crashes, blockages, unexpected system downtimes, etc. due to the use of non-approved spare parts

- ▷ Use only approved spare parts.

Falling products

Improper transport of the product can result in serious injury or death.

- ▷ Only use suitable lifting and transport equipment.
- ▷ Make sure that lifting or transport equipment is approved for the specified weight.

Suspended loads

Serious or fatal injuries may result.

- ▷ Do not walk under suspended loads.

Unsecured loads

Serious or fatal injuries may result.

The product can also be equipped with a manual release. Manually releasing the de-energized motor can cause loads to move freely.

- ▷ Before operating the manual release: Secure loads.
- ▷ After manual release (with lockable manual release): First release the locking mechanism, then release the load.

Improper transport, storage and installation

Improper transport, storage, and installation can damage corrosion-resistant paint coatings and lead to corrosion. Mechanical damage (scratches, chipping), chemical degradation by acids or alkalis or thermal damage caused by sparks, welding beads and heat lead to corrosion and failure of the external protection.

- ▷ Make sure that paint coatings are protected properly during transport, storage and installation.
- ▷ Have damage to paint coating repaired professionally. Observe permissible paint layer thicknesses.

Exceeding permissible limit values

Heat, centrifugal force, and demagnetisation in the permanent magnets can lead to overloading, damage to the system/machine.

- ▷ Use the values for torque limit, limiting currents, and limit speed on the rating plate.

Attachment element pressure points

Pressure marks from attachment elements can damage corrosion-resistant paint coatings and lead to corrosion.







- ▷ Have damage to paint coating repaired professionally.

Incorrect installation positions and ambient temperatures

Material damage may occur

- ▷ Ensure compliance with the specified permissible installation orientations and ambient temperature ranges.

2.5 Pictograms on product

Symbol	Meaning
	The geared motor is suitable for use in potentially explosive atmospheres.
	This is not a lifting point.
	Hot surface, can cause burns.
	Operate permanent magnet synchronous motor only via inverter.
	Rotation direction of the geared motor
	Products and accessories may be subject to country-specific regulations implementing the WEEE directive (Waste Electrical and Electronic Equipment). Disposal of the product and all accessories must therefore be carried out in accordance with the statutory disposal and return regulations in force in your country.

2.6 Personal protective equipment

All specialist personnel must wear the necessary work/protective clothing.

- ▶ Wear hearing protection for high noise emissions.
- ▶ Wear suitable protective gloves if coming into contact with hot or frozen components.
- ▶ Wear safety shoes.
- ▶ Wear safety glasses when installing electrical equipment.

2.7 Safety devices

Do not disable local monitoring and protection devices when working on the product.

2.8 Environmental protection and disposal

- ▶ Dispose of motors in accordance with applicable local regulations.
- ▶ Collect old lubricant (waste oil, grease) and dispose of properly.


3 Product description

3.1 Product identification: motor

Motors are used to drive slow-running machines, devices, and systems. Products are identified using the type codes described below.

3.1.1 Rating plate/type plate


All essential data and information is stated on the rating plate in accordance with EN 60034.



Example illustration of the rating plates

- | | |
|---|---|
| <ul style="list-style-type: none"> 1 Manufacturer 2 Motor number 3 Article number 4 Production date (week/year) 5 Type designation 6 Space for additional information 7 Energy efficiency 8 Rated power 9 Power factor 10 Operating mode 11 Heat class 12 Rated frequency 13 Motor connection (e.g. Y) 14 Rated voltage 15 Rated current 16 Rated motor speed 17 Space for inverter duty cycle | <ul style="list-style-type: none"> 18 Space for inverter duty frequency range 19 Space for inverter duty voltage range 20 Space for inverter duty output range 21 With brake installed: DC voltage 22 DC current of brake 23 With brake installed: Braking torque on motor shaft 24 With brake installed: AC connection voltage 25 AC current of brake 26 With brake installed: Braking torque on motor shaft 27 Installation position 28 Permissible ambient temperature range 29 Protection rating 30 Drive weight 31 Approvals 32 Standards complied with |
|---|---|

3.2 Type code/type designation




- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Motor type, size, and integrated designs | <ul style="list-style-type: none"> 2 Motor attachments 3 Additional options |
|--|---|

A complete breakdown can be found in all of our catalogues in chapter 3, see www.bauergears.com.


3.3 Motor type designation

Motor / **Brake**
D..09L A 4 - TF - S / ES 010 A 9 HN / C2



Three-phase motor	D	= Three-phase motor
	E	= Single-phase motor (masonry circuit)
	S	= PM synchronous motors
	• A	= Aseptic motor = germ control drive
	• SE	= Three-phase motor with increased efficiency according to IE1
	• HE	= Three-phase motor with increased efficiency according to IE2
	• PE	= Three-phase motor with increased efficiency according to IE3
	• N	= Motor without gearbox, motor in foot-mount version
	• NF	= Motor without gearbox, motor in flange version
	• R	= Roller conveyor motor
	• XE	= Explosion-protected motor with increased safety
	• XD	= Pressure-resistant
	• W	= Rotating-field magnet
	• L	= Special rotor for traction and rotary motors
	• C	= with main and auxiliary windings (single-phase motors only: EC....)
	• V	= Wide-range voltage
	• U	= Unventilated (i.e. also without fan)
Motor protection	TB	= Thermistors 140°
	TF	= Thermistors 160°
	TH	= Thermistors 180°
	TEB	= Thermistor warning/trip 120°/140°
	TBF	= Thermistor warning/trip 140°/160°
	TFH	= Thermistor warning/trip 160°/180°
	TOB	= Thermostat, opener 140°
	TOF	= Thermostat, opener 160°
	TOH	= Thermostat, opener 180°
	TSB	= Thermostat, closer 125°
	TSF	= Thermostat, closer 160°
	TSH	= Thermostat, closer 180°
	TX	= other
Brake rectifier in the motor terminal box	S	= Standard rectifier SG
	E	= Special rectifier ESG
	M	= Special rectifier MSG
Plug-in connection	ST	= Harting (andere)
Heavy fan	SL	
Protective hood	D	
CleanDrive	CD	= Aseptic drive with cable

3.4 Type designation of motor attachments



Brake	E ES EH ZS ESX EHX ZSX	= Single-disc brakes = Single-disc holding brake = Holding brake, single-disc, heavy-duty version = Double-disc holding brake = Single-disc service brake = Single-disc working brake in heavy-duty version = Dual-disc service brake
	010 ... A 9 HN HA	= Brake size = Build status = Code number of the set braking torque = Manual release (not lockable) = Manual release (lockable)
Backstop	RR RL	= Locking direction right = Locking direction left
Digital and analogue sensors	G	
Second motor shaft end	ZW ZV	= with key = with square
External ventilation	FV	
Overall design	AV AM UL CS C1 C2 C3 C4 C5-I C5-M IM2 SP	= USA/Canada version with shaft dimensions in inches = USA/Canada version with metric shaft dimensions = US version = Canadian version = Anti-corrosive protection Coro1 = Anti-corrosive protection Coro2 = Anti-corrosive protection Coro3 = Anti-corrosive protection Coro4 = Corrosion protection Coro5 (industrial) = Corrosion protection Coro5 (marine) = Protection against sea or brackish water = Non-catalogue version

3.4.1 Installation positions




Fig. 1: mounting positions

3.5 Functional description

3.5.1 Three-phase motor

Induction motor

Bauer motors for three-phase connection are supplied with specially designed asynchronous technology. This design enables maximum operational reliability with high torque and low inrush current.

Permanent magnet synchronous motor

PMSM motor rotors are equipped with embedded permanent magnets.

3.5.2 Brakes

Spring-loaded brakes

In addition to holding loads at rest (holding brakes), the spring-loaded brake is used to decelerate masses rotating and moving linearly (service brakes) in order to shorten undesired over-travel distances and times. The brake releases electromagnetically.

When de-energized, braking force is generated by spring pressure.

Since this system also applies braking in the event of an unintentional power failure, it can be regarded as a safety brake in the sense of accident prevention regulations.

During braking, the kinetic energy of the moments of inertia is converted into heat via the brake disc. The asbestos-free brake disc is resistant to wear and heat.

Service brakes

During normal operation, the brakes perform friction work, i.e., they perform a slowdown function. Service brakes are required to brake rotating or translational masses in a defined manner, e.g. for positioning tasks, holding loads, etc. In so doing, they convert kinetic energy into heat. For physical reasons, some wear is unavoidable to maintain braking torque and performance.

Example service brakes are spring-loaded brakes of type E003B and E004B (each with DC release solenoid).

Holding brakes

Spring-loaded brakes ES010A ... ES250A, ZS300A and ZS500A are holding brakes that do not perform friction work during normal operation, rather they secure an approached position. In an emergency, they perform a slowdown function.

Spring-loaded brakes ESX010A ... ESX250A, ZSX300A and ZSX500A are service brakes that perform friction work during normal operation, i.e., they perform a slowdown function.

Brake attachment

- ES and ESX: Brakes are attached under the fan cover
- EH and EHX: Brakes are attached on the fan cover

Example service brakes are spring-loaded brakes of type ES(X)010A ... ES(X)300A, ZS(X)300 and ZS(X)500A (each with DC release solenoid)

3.5.3 Encoder system

Incremental rotary encoders

Incremental rotary encoders (impulse generators/encoders) determine the position of motor shafts. Rotational movement is processed by the incremental rotary encoder and output as an electrical signal. An impulse disc with a certain number of periods per revolution detects step angles.

Absolute rotary encoders

Absolute rotary encoders detect both angular and rotational movements and convert these into electrical signals.

3.5.4 Backstop (RR, RL)

Specify blocking direction right (RR) or left (RL) when ordering.
The reference is a view of the mounting side.

3.5.5 Second motor shaft end (ZW, ZV)

With this shaft end, half of the rated power can be transferred with a central drive. Permissible radial load on request. Covers are not included with delivery.

3.5.6 Rain cover above fan cover (D)

For outdoor installation with significant or long-lasting exposure to water, we recommended using a rain cover over the fan cover if the motor points upwards.

3.5.7 Motor heating

To dry motor windings after long storage periods, the motor can be heated actively, e.g. standstill heating via heater bands, see also chapter 6.4.10, p. 29.

Heating is also provided in order to ensure that the motors start up reliably after being idle for a long period of time in very cold locations.

4 Included with delivery

The motor is delivered as a ready-to-use unit.

5 Transport and storage

5.1 Goods Receiving

NOTICE**Incomplete and damaged products**

Obstruction and complication of operational processes

▷ Do not install or commission damaged products.

- ▶ Immediately check delivery for completeness upon receipt.
- ▶ Verify that the technical design of the product corresponds to the order.
- ▶ Check rating plate.
- ▶ Inspect products for packaging and shipping damage.
- ▶ Report any damage to the transport company immediately.

The product is delivered assembled.

Any additional equipment is supplied separately and packaged as an “accessory pack”.

5.2 Transportation

NOTICE**Improper transport**

Material damage may result. The ring eyelet attached close to the centre of gravity does not guarantee that the product will remain in a horizontal position.

- ▷ Observe the specifications for proper transport.
 - ▷ Lift the product slowly and ensure that it remains in a horizontal position by attaching the lifting gear (additional loops) appropriately.
 - ▷ Do not install or commission damaged products..
-

With our products, only eye bolts pursuant to DIN 580 are permitted for use as lifting points for lifting equipment. The eye bolts are only designed for the weight force of the motor. Additional loads are not permitted. Only one lifting point is provided per product.

- ▶ When lifting and transporting heavy loads, follow internal factory specifications for handling loads.
- ▶ Only use suitable lifting and transport equipment.
- ▶ See the rating plate for the product weight.
- ▶ Make sure that the lifting or transport equipment is approved for the specified weight.
- ▶ Only use the provided lifting points for lifting and transporting.
- ▶ Make sure that the eye bolts are completely tightened.
 - The eye bolt(s) should lie flat on the housing surface.

5.3 Storage

NOTICE

Improper storage

Material damage may result.

- ▷ Observe the specifications for proper storage.
 - ▷ Do not install or commission improperly stored products.
-

5.3.1 Short-term storage

If the product is not installed immediately as intended, it can be stored for up to 9 months without taking any special measures.

- ▶ Store product in a dry place.
- ▶ Avoid temperature fluctuations outside the normal range of -20 to +40 °C.
- ▶ Do not subject product to shocks or vibrations.
- ▶ Have transport damage to paint or corrosion protection repaired professionally.

5.3.2 Long-term storage

- Storage space requirements
- Storage space is dry, dust-free, ventilated, and free of vibrations (permissible vibrations $v_{\text{eff}} < 0.2$ mm/s).
- Storage temperature range: -20°C to +40°C with minor fluctuations.
- Air in the room should be free from aggressive, corrosive, or radioactive elements.
- Do not expose product to direct sunlight or any other source of UV radiation.

Preparation for storage

NOTICE

Improper storage

Improper storage can damage corrosion-resistant paint layers and thus lead to corrosion. Mechanical damage (scratches, slivers), chemical corrosion from acids or alkali, or thermal damage from flying sparks, welding beads, and heat will cause the external protection to deteriorate and fail.

- ▷ Observe the specifications for proper storage.
-

- ▶ Check the exterior paintwork. Repair any damage if necessary. Observe the permissible paint layer thicknesses.
- ▶ Check the corrosion protection on bare metal parts (shafts, hollow shafts, flanges, etc.). Repair any damage if necessary.

During the storage time

Do not stack products on top of each other.

- ▶ Store the product on a hollow base.
- ▶ Cover product when stored.
- ▶ To prevent the sealing ring/sealing lips from sticking or hardening, we recommend turning the product every six months.

6 Installation

6.1 Requirements for installation site

6.1.1 Substructure

- The substructure is torsion-resistant and vibration-damping.

6.1.2 Cooling air supply

- Cooling air supply to the motor is unobstructed (at least 10 cm away from the air inlet in the fan cover).

6.1.3 Installation outdoors or in damp rooms

Motors starting from motor size 63 (D06...) are suitable as standard for protection rating IP65 and for use outdoors or in damp rooms. For corrosion reasons, use increased corrosion protection (CORO1 ... CORO5-M and Im2).

Direct sunlight, e.g. when installed outdoors, is not permitted.

- ▶ Use suitable covers that do not accumulate heat.
- ▶ Have any damage to paint coating caused during transport, installation, and assembly repaired professionally before commissioning.
- ▶ For vertical installation (motor up), select the option "Rain cover" above the fan cover.
- ▶ Check the product at regular intervals with regard to fastening and tightness of cabling.
- ▶ Remove any deposits of dust and dirt.

6.1.4 Installation of roller table drives

In addition to the general specifications in chapter 6, p. 20, note the following when installing roller table drives:

- ▶ Shield the product against long-term or significant water exposure.
- ▶ Protect the product from strong radiant heat by means of suitable shielding.

6.2 Mechanical installation

6.2.1 Required tools and aids

The following tools and aids are required for mechanical installation:

- Disassembly/assembly aids
- Transport devices
- Lifting equipment
- Hand tools such as wrenches, screwdrivers, etc.
- Torque wrench for checking tightening torques
- Screw locking agent, e.g. Loctite®
- Use fixing screws of strength class 8.8 at least.

6.2.2 Inspections and preparatory work before installation



CAUTION

Sharp edges on open keyways

Cutting injuries may result

- ▷ Insert the key into the keyway

Work can only be carried out if the following requirements are met:

- Product is not damaged or leaking.
- The information on the product rating plate matches the requirements with regard to power, speed, voltage, frequency, and ambient temperature in particular.
- Any potential dirt and anti-corrosion agents on flange surfaces, fittings, and output shafts have been removed.

In abrasive, aggressive, or corrosive ambient conditions, only use the product if it is appropriately dimensioned and designed.

If in doubt, consult Bauer Gear Motor.

- ▶ Check the direction of rotation when not coupled. (For information on electrical connection, see chapter 6.4, p. 22 if hazards and/or material damage are expected if the output shaft rotates in the wrong direction).
- ▶ For products with backstop, check that the working direction (see arrow) corresponds to the required direction of rotation.
- ▶ When connecting, make sure that the output shaft rotates in the correct direction. In case of doubt, perform a rotary field test.

6.2.3 Drive elements

NOTICE

Material damage due to improper installation of drive elements

This may result in damage to the bearing.

- ▷ Heat drive elements, such as pinions or couplings, before assembly.
-



DANGER

Ejection of unsecured keys from the keyway

This can result in serious or even fatal injuries caused by flying debris.

- ▷ Drive with the customer's drive element fitted or the key suitably secured operate.
-

6.2.4 Motor with second shaft end

Engines with an optional ZW second motor shaft end are delivered with the key inserted and secured for transportation.



DANGER

Ejection of unsecured keys from the keyway

This can result in serious or even fatal injuries caused by flying debris.

- ▷ Operate the drive with the customer's drive element fitted or suitably secured key.
-



DANGER

Rotating parts.

Serious to fatal injuries are the result.

- ▷ If no protection is provided on site, install a protective cover in accordance with accident prevention regulations.
-

6.3 Installation of standard motors

Tightening torques for the clamping bolts of standard motors with IEC frame sizes 56 to 280 and NEMA 56C to 405TC.

► Use the following tightening torques:

IEC motor size	Bolt	Tightening torque [Nm]
56	M6	10.1
63	M6	10.1
71	M6	10.1
80	M8	24.6
90	M8	24.6
112	M8	24.6
132	M12	84
160	M12	84
180	M12	84
200	M16	206
225	M16	206
250	M16	206
280	M16	206

Tab. 1: Tightening torques for tensioning screws

6.4 Electrical installation

Before performing any work, read and follow the safety instructions described in chapter 2, p. 9. All work with the product must be performed by qualified and trained specialist personnel.

Also follow:

- Plant-specific and local regulations and requirements
- Safety barriers and warning and safety signs specified on site.

► If product was stored for a long period of time (>9 months / long-term storage): Prepare the product before installation in accordance with the specifications in chapter 5.3.2, p. 19.



The connection diagrams for the respective motor are attached in the terminal box cover of the product.

6.4.1 Required tools and aids

- Chisel or similar
- Hammer
- Screwdriver
- Hexagonal wrench

6.4.2 Prerequisites



WARNING

Improperly performed work

Serious or fatal injuries may result.

▷ Observe and comply with all the requirements described.

Only suitably qualified personnel in accordance with EN 50110-1/-2 (VDE 0105 Part 100) may perform work on this device or system.

- Remove any transport locks before putting the device into service.

Before starting installation

- ▶ Before performing any work, read and follow the safety instructions described in chapter 2, p. 9.
- ▶ Comply with the general installation regulations.
 - Carry out the electrical installation in accordance with the relevant regulations (e.g. cable cross-sections, fuses, protective conductor connection).
- ▶ In addition, observe the following regulations, requirements and safety measures:
 - Plant-specific and local regulations and requirements
 - Safety barriers and warning and safety signs specified on site.
- ▶ Only install the product if the mains voltage and frequency match the voltage and frequency data on the rating plate of the motor, or, in the case of inverter duty, the output voltage of the inverter matches the connection voltage of the motor, see chapter 3.1.1, p. 13 and drive rating plate.

Preparing for installation

- ▶ Observe the assembly instructions specified for the product.
- ▶ Observe the 5 safety rules in accordance with DIN VDE 0105.
 - Switch off the system.
 - Protect the system from being switched on again.
 - Check that no voltage is present.
 - Cover or fence off nearby live parts.
 - Earth and short out the device.
- ▶ Use original spare parts for each repair.

Performing installation

- ▶ Electrical connection of the motor must be made according to the connection diagram enclosed in the terminal box.
- ▶ If the connection diagram is missing: Do not connect the motor. An approved connection diagram can be requested from Bauer Gear Motor GmbH.
- ▶ Check the seal of the terminal box for damage after opening. If damaged, replace with original parts (sealing material and adhesive).
- ▶ Only use the original connecting parts supplied.
- ▶ If unexpected start-up of the system can endanger personnel, do not use motor protection devices with automatic restart.
- ▶ Connect motor and control, overload protection and earthing according to local installation regulations.

Installation after a long storage period

- ▶ If product was stored for a long period of time (>9 months / long-term storage): Prepare the product before installation in accordance with the specifications in chapter 5.3.2, p. 19.

6.4.3 Open cable entry of cast-on terminal box (D..04.. to D..11..)**WARNING****Loose, unsecured parts**

Eye injury can be the result


- ▷ Wear safety glasses.

1. For third-party engines, follow the instructions in the engine manufacturer's operating manual.
2. Fit terminal box cover
3. Place chisel or similar at a slight angle on the cable entry to be opened and hammer it in lightly.

NOTICE**Material damage due to incorrect use of tool**

Risk of damage to terminal box

- ▷ Do not punch tool through.





4. Unscrew terminal box cover and remove broken-out parts.
5. Fasten cable gland with enclosed lock nut. When doing so, use the installation torques specified by the cable gland manufacturer.
6. Tighten the terminal box cover with a tightening torque of 1-1.5 Nm to ensure terminal box cover sealing.

6.4.4 Electrical connection on terminal block

Make the electrical connection according to the connection diagram. A terminal block with cage spring clamps (CAGE CLAMP®) is installed as standard.

Terminal block with CAGE CLAMP® technology



- 6 terminals for winding
- 1 terminal for PE
- 4 auxiliary terminals in different sizes and colours (e.g. thermistors for warnings and shutdown)
- Star connection W2-U2-V2 fitted
- The lower terminal row is for the mains connection.

1. For third-party engines, follow the instructions in the engine manufacturer's operating manual.
2. Open clamp with a suitable screwdriver: Insert screwdriver until the stop.
 - Leave screwdriver in place to hold the CAGE CLAMP®.
3. Insert cable: Insert the approx. 10 mm long insulated single-wire, fine-wire, or crimped connection wire. For fine-wire connection wires, ensure that no splices protrude out.




4. Pull out screwdriver.
 - Cable is clamped automatically.
5. Once the connection is complete, screw on the terminal box cover. Make sure that no cable strands are crushed. Ensure that the seal is seated correctly.
6. After completing work: Have any damage to paint coating repaired professionally to ensure corrosion protection.

6.4.5 Electrical connection on terminal board

Optionally available

Motor with terminal board with screw bolts installed in terminal box

- ▶ For third-party engines, follow the instructions in the engine manufacturer’s operating manual.
- ▶ Make connection according to following sketch. Use the tightening torques in accordance with Tab. 3, p. 26.



Tab. 2: Connection of single-wire conductor; version with stud terminal

- ▶ Use the following tightening torques:

Nut	Tightening torque [Nm]
M4	1.6
M5	2.0
M6	3.0
M8	6.0

Tab. 3: Tightening torques for electrical connection on terminal board

- ▶ Do not route connecting lines over electrically live parts.

Additional terminals for temperature monitoring or standstill heating are located in the main connection compartment or in supplementary connection compartments, depending on the version (see supplied wiring diagram).

- ▶ Keep the supplied wiring diagram (in the connection compartment) with the drive documents in the plant.

Connect external fan

- ▶ For third-party motors, follow the instructions in the motor manufacturer’s operating manual.
- If an external fan is provided, it must always be switched on together with the motor, and with duty type S3 or S4 it should operate continuously with the motor as much as possible.
- ▶ Connect external fan (see chapter 16.3.1, p. 43).

Ensure protection against contact with electrically live parts

- ▶ For third-party motors, follow the instructions in the motor manufacturer’s operating manual.
- 1. Close the terminal box again using the seals provided at the factory and in compliance with the IP protection class.
- 2. Check the seal of the terminal box and replace with original parts if damaged.
- 3. Ensure that the insertion parts comply with the IP rating of the motor as a minimum.
- 4. Seal unused insertion holes with approved (e.g. metal) seal plugs with sealing rings at least IP protection class of the motor.
 - If the supplied cable entries have caps, they are only intended to provide protection during transport and are not approved seals. This also applies to outdoor storage of motors. Additional rain protection is necessary in such case.

Motors with cast-on terminal boxes

- ▶ For third-party motors, follow the instructions in the motor manufacturer’s operating manual.
- ▶ Observe operating instructions for cable and line entries.
- ▶ Ensure that the diameters of the cables and connectors used correspond to the clamping range marked on the entry.

Cable entries and entry seals that do not meet these requirements are not permitted.

Motors with screwed-on terminal boxes

- ▶ For third-party motors, follow the instructions in the motor manufacturer’s operating manual.
- ▶ Observe operating instructions for cable and line entries.
- ▶ Ensure that the diameters of the cables and connectors used correspond to the clamping range marked on the entry.

Cable entries and entry seals that do not meet these requirements are not permitted.

To change the position of the cable and conductor entries, the compartment can be rotated in four steps of 90°.

1. Screw on the terminal box cover.
2. Loosen and remove four screws in the corners at the bottom of the terminal box.
3. Loosen the terminal box from the motor housing and rotate it.
 - To do this, undo the motor connection if necessary and, after aligning the terminal box, reconnect it according to the information in chapter 6.4.4, p. 25, 6.4.5, p. 26 and chapter 6.4.7, p. 28.
4. Check the seal of the terminal box and replace with original parts if damaged.
5. Screw the terminal box to a motor housing and tighten to the tightening torque specified Tab. 4, p. 27 to ensure that the terminal box is leaktight.

Thread size	Tightening torque [Nm]
M4	2.5
M5	5.5
M6	10.0
M8	20.0

Tab. 4: Tightening torques for terminal box screw connection

6. Check the seal of the terminal box on the cover and replace with original part if damaged.
7. Ensure that the cover of the terminal box is leak-tight
 - To do this, tighten the terminal box cover with a tightening torque in accordance with Tab. 3, p. 26.

6.4.6 Electrical connection with plug-in connection on terminal box, CleanConnect® plug, or cable version (CleanDrive)

Optionally available

Product with following connection variants:

Connection variant	Description	Connection diagram	Remarks
Plug-in connection on terminal box	Plug installed on terminal box for electrical connection	Included with delivery	-
CleanConnect® plug	AsepticDrives equipped with CleanConnect® stainless steel circular connector, protection rating IP67/IP69K	Included with delivery	pH2 to pH12 cleaners are permitted for cleaning when using the supplied or recommended power cables.
Cable version (CleanDrive)	Can also be equipped with cable version with stainless steel screw connection, protection rating IP67	Included with delivery	pH2 to pH12 cleaners are permitted for cleaning.

Tab. 5: Electrical connection variants – properties and information



If the connector is supplied, read supplied documentation.

6.4.7 Protective earthing

- ▶ Establish standard earthing via protective conductors in respective motor terminal box. When connecting the earthing cable, make sure that the connection conducts well.

Optionally available

For corresponding requirements: Drive with easily accessible earthing screw mounted on outside of motor housing to optimise earthing.

6.4.8 Contact protection

If voltage is present, e.g. in testing and commissioning phases with open terminal box:

- ▶ Make sure that no one is standing in the hazard area.
- ▶ Attach contact guards, warning signs, barriers, or similar in accordance with safety specifications.

6.4.9 Electrical connection for motor protection devices



WARNING

Automatic restart

After the winding has cooled down, it may restart automatically. This can result in serious or fatal injuries.

- ▷ Prevent restarting via switching.

- ▶ Use motor protection switches to protect the winding against overload and against the consequences of operating on only two mains supply lines, e.g. in the event of phase failure.
- ▶ Set the motor protection switch to the rated current at the respective rated voltage of the motor, see rating plate.

6.4.10 Stator standstill heating

NOTICE

Incorrect connection voltage for auxiliary heating via heater bands

Motor damage and material damage due to drive failure can result.

- ▷ Note the connection voltage, see rating plate.
- ▷ Only switch on the heater bands when at a standstill.
- ▷ Apply the heating voltage (AC voltage) according to the wiring diagram of the parking heater.




Fig. 2: Connection diagram for stator standstill heating via heater bands

6.4.11 Electrical connection for brakes

- ▶ When making electrical connection for brakes: Follow factory regulations or rules from professional associations for connecting brakes, e.g. phase failure protection or other safety circuits.

There are 2 options for supplying power to the DC solenoid:

- Externally from an existing DC control network or through a rectifier in the control cabinet.
- Through a rectifier mounted in the motor or brake terminal box. In this case, the rectifier can be supplied either directly from the motor terminal board or terminal block or from the mains.

Do **not** connect the rectifier to the motor terminal board or terminal block in the following cases:

- Pole-changing motors and wide-voltage motors
 - Frequency inverter duty
 - Other versions where motor voltage is not constant, e.g. operation on soft starters, starting transformers, etc.
- ▶ Make the electrical connection for the brake according to the connection diagram (included with motor with every delivery - see Tab. 6, p. 30).

Supply voltage of brake	Rectifier type	Supply voltage of rectifier	Switch-off Brake supply	Connection diagram	Additional connection diagram
External DC connection	-	-	-	A311.1000-25	-
Rectifier	SG3.575B	Motor terminal board or terminal block	AC-side	A311.1000-26	Z011.1000-25
			DC-side	A311.1000-27	Z011.1000-25
		Separate	AC-side	A311.1000-28	-
			DC-side	A311.1000-29	-
	ESG1.460A	Motor terminal board or terminal block	Automatic	A311.1000-30	Z011.1000-25
		Separate	Automatic	A311.1000-31	-
	MSG1.5.500U	Separate	Automatic	A311.1000-32	-
	MSG1.5.480I	Motor terminal board or terminal block	Automatic	A311.1000-33	Z011.1000-25

Tab. 6: Brake connection options



Clampable conductor cross-section of rectifier: max. 1.5 mm²
 For SG rectifiers: max. 1.0 mm² when using ferrules

Operation using rectifier ESG1.460A

- To activate the integrated quick shut-off function, connect the blue conductor leading out of the housing to PE. Since this conductor is coupled to the supply voltage with high impedance, leakage currents of up to max. 2 mA can flow, depending on the voltage level.
- If the motor undergoes high-voltage testing, the blue wire of the rectifier must be disconnected from the PE beforehand.
- For operation on ungrounded networks, the blue conductor must be connected to the right AC voltage contact (N) of the electronic fast-acting rectifier. If, in this case, the rectifier is supplied by the motor terminal board, an increase in the response time must be expected when switching off.

Operation using rectifier MSG1.5.480I

NOTICE

Motor supply cable not routed through sensor

The rectifier does not switch on and can be damaged.

▷ Make sure that a motor supply cable is routed correctly through the current sensor.

The current sensor is used to detect the motor current. For the rectifier to function correctly, a motor supply cable must be routed through the sensor.

Technical specifications of sensor

- Maximum continuous current rating: 64 A
- Sensor bore diameter: 7 mm
- Permissible wire diameter:
 - 1x passage: max. 6.7 mm
 - 2x passage: max. 3.2 mm

Connecting the sensor

- Pass one wire of the motor connection cable through the hole in the current sensor, which is mounted on the side of the rectifier.
- For engine no-load currents < 0.4 A, the wire must be guided twice through the sensor hole. In this case, the rectifier below the sensor is marked with sticker "2".




Fig. 3: MSG1.5.480I rectifier sensor

6.4.12 Electrical connection for external fan

NOTICE

Incorrect connection of external fan

Material damage and financial losses caused by a system malfunction due to motor failure may occur because the external fan cannot cool during downtimes or does not supply enough cooling air at low frequencies (inverter duty).

▷ Make electrical connection for external fan separately (not on motor terminal board) for intermittent, periodic, or frequency inverter duty.

- ▶ Make the electrical connection for the external fan in accordance with the connection diagram (included with motor with every delivery).
 - For possible connection voltages, see Tab. 13, p. 43.

6.4.13 Encoder electrical connection

- ▶ Establish the electrical connection for the encoders in accordance with the manufacturer's operating manual supplied with the product.

6.4.14 Connection for motors with plug

- ▶ Information on connecting motors with plugs: Read motor data sheet.



When connecting, follow manufacturer's documentation for plug.

6.4.15 Connection of rotating field magnet motors

NOTICE

Property damage due to improper use of tooling

Risk of damage to the terminal box

- ▷ If the rotary field magnet is operated on a frequency converter **without** an output filter, the varistors in the motor terminal box must be disconnected.

7 Commissioning



CAUTION

High noise emissions

Hearing damage may occur.

- ▷ Wear hearing protection.

- ▶ Observe the values on the rating plate.
- ▶ Follow instructions in chapters Tab. 2, p. 26, 6.2, p. 20 and 6.4, p. 22.
- ▶ Observe motor speeds, e.g. with inverter duty, for frequency inverter possibly being used.



For existing options, e.g. encoders, follow the operating manual supplied by the manufacturer.

7.1 Checks before commissioning

- ▶ Before commissioning the product, check the following:
 - Integrity
 - No leaks
 - Fasten the drive and transmission elements with the necessary screws and torques
 - Transmission elements such as chains or belts are tensioned according to specification.
 - Possible torque arms are placed correctly and rubber buffers are pre-stressed.
 - Safety devices and covers are correctly mounted on both the drive and the system/machine.
 - All electrical cables are correctly laid and connected.
 - Cable glands are tightened and sealed as necessary.
 - Motor protection switches are set to the rated current and, if necessary, other motor protection devices are activated.
 - Cooling air supply to the motor is unobstructed.
 - Any existing brake is set to the projected braking torque.
 - Existing brake is working in accordance with requirements and does not lock in place, particularly during lifting operations, and existing manual release lever has been removed.
 - The direction of rotation is correct. U, V, W on L1, L2, L3 give a clockwise rotation of the motor when looking at the motor shaft.

7.2 Initial commissioning

- Installation position according to rating plate.
- ▶ For motors with backstop: The permissible motor rotation direction is marked with an arrow on the fan cover. Start the motor in the permissible direction of rotation. Do not start motors with backstop in the blocking direction as this may damage the backstop.

7.3 Commissioning after long-term storage

7.3.1 Motor measures



WARNING
Electric shock

Serious or fatal injuries may result.

- ▷ Check the insulation resistance between all winding points and between the winding and housing. Check insulation resistance with commercially available measuring devices.

- Measured value 50 MΩ = optimal, corresponds to new
- Measured value 5 MΩ = drying advisable
- Measured value 1 MΩ = drying required

If it is necessary to dry the motor:

- ▶ Have the manufacturer or a specialist workshop for electrical machines carry out any work required. If the work is not carried out by the manufacturer:
- ▶ Have the work assessed by a recognised qualified person.

8 Normal operation

Normal operation depends on the overall situation after installing the drive in the overall system or machine.



Read and follow documentation for overall system or machine.

9 Malfunctions and troubleshooting

9.1 Motor malfunctions

Malfunction	Possible cause	Remedy
Motor not starting	No voltage connected to motor	▶ Correct connections, eliminate interruptions as necessary.
	Fuse switched off/burnt	▶ Switch on or replace fuse.
	Brake not releasing.	▶ Configure drive and connections correctly.
	Motor protection has tripped.	▶ Check motor protection configuration. ▶ Remove blockages.
	No release for inverter duty	▶ Follow operating instructions of the frequency inverter.
Motor not starting or "racking" up.	Motor runs against closed brake.	▶ Adjust brake drive and connections correctly.
	<ul style="list-style-type: none"> • Voltage drop too large • Cable cross section too small in general or for existing large cable length 	▶ Insert cable with correct cross section.
	Motor intended for delta connection, but connected in star	▶ Correct switching.
	If configured for Y-D start-up, starting torque in Y-switching too low (incorrect configuration)	▶ Eliminate tension or other additional mechanical loads in the system. ▶ Check projection, use stronger motor as necessary. ▶ Design different start-up solution. ▶

Malfunction	Possible cause	Remedy
Motor not reaching its rated speed or speed drops sharply	Motor is overloaded.	<ul style="list-style-type: none"> ▶ Eliminate overload. ▶ Measure load. ▶ Check configuration and initiate further measures as necessary.
	Voltage drop too large, cable cross section too small in general or for existing large cable length	<ul style="list-style-type: none"> ▶ Insert cable with correct cross section.
Fuses fail immediately after switching on	<ul style="list-style-type: none"> • Connected incorrectly • Short-circuit in supply line 	<ul style="list-style-type: none"> ▶ Correct the connection.
	Motor has short-circuited or shorted to ground.	<ul style="list-style-type: none"> ▶ Speak with Bauer Gear Motor in advance, this may fall under warranty. ▶ Have the motor repaired or replaced by a specialist company.
Motor protection trips immediately after switching on	<ul style="list-style-type: none"> • Connected incorrectly • Short-circuit in supply line 	<ul style="list-style-type: none"> ▶ Correct the connection.
	Motor has short-circuited or shorted to ground.	<ul style="list-style-type: none"> ▶ Speak with Bauer Gear Motor in advance, this may fall under warranty. ▶ Have the motor repaired or replaced by a specialist company.
Motor becomes too hot. ▶ If necessary, consult with Bauer Gear Motor GmbH <ul style="list-style-type: none"> • How hot does the motor get? • After what runtime? • Measured where? 	Drive is overloaded.	<ul style="list-style-type: none"> ▶ Take a power measurement. ▶ If necessary, select different drive and reconfigure.
	Connection voltage at motor terminals too high or too low (if not otherwise confirmed, $\pm 5\%$ as standard)	<ul style="list-style-type: none"> ▶ Voltage drop too large. Check connection cable cross section, correct if necessary ▶ If necessary, adjust motor to available mains voltage.
	Cooling insufficient	<ul style="list-style-type: none"> ▶ Ensure unimpeded air supply, retrofit external fans if necessary.
	Motor configured for wrong operating mode (S1 ... S10)	<ul style="list-style-type: none"> ▶ Operate the system according to the operating mode. ▶ If necessary, select different drive and reconfigure.
	Ambient temperature higher than considered during configuration	<ul style="list-style-type: none"> ▶ Consult with Bauer Gear Motor and find a solution together.
	Motor runs on 2 phases only.	<ul style="list-style-type: none"> ▶ Check fuses, connection lines. ▶ Rectify malfunction. ▶ Measure motor winding. ▶ If necessary, repair at specialist workshop.

Tab. 7: Motor malfunctions

9.2 Brake malfunctions

Malfunction	Possible cause	Remedy
Brake does not release	No voltage present.	<ul style="list-style-type: none"> ▶ Check and correct control. ▶ If possible due to connection used, place missing connection between rectifier and terminal board. ▶ Rectifier defective, replace.
	Incorrect voltage applied.	▶ Correct voltage.
	Air gap too large	Brake pads worn. <ul style="list-style-type: none"> ▶ Have repaired by trained personnel or specialist workshop
	Brake coil defective	<ul style="list-style-type: none"> ▶ Replace brake. ▶ Have repaired by trained personnel or a specialist workshop.
Drive does not brake as planned	Incorrect braking torque	▶ Have the braking torque corrected by trained personnel or a specialist workshop.
	Brake lining worn	▶ Insert new linings and friction discs, have repaired by trained personnel or specialist workshop.
	Air gap too large	<ul style="list-style-type: none"> ▶ Adjust air gap or replace friction discs. ▶ Have repaired by trained personnel or a specialist workshop.
Brake engages too slowly	Incorrect control selected	<ul style="list-style-type: none"> ▶ Install DC-side switch-off. or ▶ Use electronic or overexcitation fast-acting rectifiers.
Brake wear is high (especially with higher switching frequency)	When the motor is switched on, it moves off against the closed brake until it is released, see chapter 6.4, p. 22.	▶ Use overexcitation fast-acting rectifiers.
Brake rattling	Usually occurs due to alternating torques on inverter duty.	▶ Configure inverter correctly.

Tab. 8: Brake malfunctions

10 Repair

NOTICE

Property damage

This may result in damage to drives and the surrounding area/system.

- ▷ Avoid damage to paint coating.
- ▷ For drives with corrosion class C4, C5, IM2, and aseptic: Have repaired only by Bauer contract partners or at the main plant.

Any work on the products must be performed by qualified specialist personnel.

- ▶ Follow the troubleshooting instructions in chapter 9, p. 33.

Repairs must be made in compliance with chapters 2, p. 9, 6.2, p. 20, 6.4, p. 22, 7, p. 32, 8, p. 33, and, 15, p. 42 by authorised personnel trained on the product.

► Use only original spare parts.

Bauer Gear Motor GmbH assumes no liability or guarantee in the event of non-compliance.

NOTICE

Damage to property

Possible damage to drives and environment/system

▷ Avoid damage to paint coating.

▷ For drives with corrosion class C4, C5, IM2, and aseptic: Have repaired only by Bauer contract partners or at the main plant.

11 Maintenance



WARNING

Inadequate maintenance

Death and serious injuries may result.

▷ Observe maintenance and inspection intervals.

NOTICE

Material damage

Damage to drives and surroundings/system possible

▷ For all maintenance work, observe the installation position according to the type plate (see chapter 3.1.1, p. 13).

▷ Do not change the installation position.

11.1 Maintenance schedule

Assembly	Component	Maintenance interval	Activities
Motor part and attachments	Entire motor	Every 10,000 hours or earlier, e.g. based on operational experience and specifications for: <ul style="list-style-type: none"> • Ambient temperatures >40 °C • Difficult operating conditions such as switching and reversing duty • For shock and vibration loads 	See chapter 11.2, p. 37
	Brake	Holding brake: Inspect every 2 years Service brake: Every six months or according to specifications from system manufacturer or system operator	See chapter 11.3, p. 38
	Encoder	every motor maintenance	See separate operating manual from manufacturer
	Backstop	every motor maintenance	See separate operating manual from manufacturer

Assembly	Component	Maintenance interval	Activities
Brakes	E003B and E004B	Holding brake: Every 2 years Service brake: Every 3,000 operating hours, every six months at the latest, or according to specifications from system manufacturer or operator	See chapter 11.3.1, p. 38
	Single-disc brakes: ES010A ... ES250A, EH027A ... EH400A	Holding brake: Every 2 years Service brake: Every 3,000 operating hours Note: • Brakes type "E..." are installed under the fan cover. • Brakes type "EH..." are installed on the fan cover.	See chapter 11.3.2, p. 39
	Single-disc brakes: ESX010A ... ESX250A, EHX027A ... EHX400A	Service brake: Every 3,000 operating hours, every 6 months at the latest, or according to specifications from system manufacturer and/or operator Note: • Brakes type "ESX" are installed under the fan cover • Brakes type "EHX..." are installed on the fan cover.	See chapter 11.3.3, p. 40
	Double-disc brakes: ZS300A ... ZS500A	Holding brake: Every 2 years Note: Brakes of type "Z..." are installed under the fan cover.	See chapter 11.3.4, p. 40
	Double-disc brakes: ZSX300A ... ZSX500A	Service brake: Every 3,000 operating hours, every 6 months at the latest, or according to specifications from system manufacturer and/or operator Note: Brakes type "ZSX..." are installed under the fan cowl	See chapter 11.3.5, p. 41

Tab. 9: Maintenance schedule

11.2 Motor inspection and maintenance

The motors must be inspected at regular intervals by a qualified specialist.

- ▶ Pay special attention to the following:
 - Possible damage
 - Noticeable noises and vibrations
 - Correct and proper electrical connection
 - Unobstructed cooling air supply
 - No impermissible dirt or dust deposits present

- ▶ Check roller bearings and replace as necessary.
 - We do not recommended cleaning and relubricating the bearings due to the risk of contamination.
- ▶ Check sealing ring running surfaces. For non-permissible run-in grooves, replace the sleeves or, in the case of motors D..04LA.. - D..07LA.., replace the rotors.
- ▶ Replace shaft sealing ring. Grease the sealing lips before inserting and, if present, fill 50% of the grease chamber between the dust and sealing lips (see Tab. 10, p. 38).
 - Make sure that the new sealing ring does not return to the "old" track.
- ▶ Also remove dirt and dust deposits near the cooling air supply.
- ▶ Touch up paint/corrosion protection, replace as necessary.

11.3 Inspection and maintenance of brakes

- ▶ Replace shaft sealing ring. Before installation, grease the sealing lips and, if present, fill the grease cavity between the dust lip and the sealing lip to 50% with grease (see Tab. 10, p. 38).
 - Make sure that the new sealing ring does not return to the "old" track.

Applicability	Bearing grease type or similar
Standard	SHELL S2 V100 3
High temperature	KLÜBER PETAMO GHY 133
Food & beverage	MOBIL Polyrex 222

Tab. 10: Lubricant chart



WARNING

Non-functional brake

Brakes are components important for safety. Death and serious injury may result.

- ▷ Any work must be performed by qualified and personnel trained on the product.
- ▷ Do not expose any friction surfaces and brake discs to oil or grease. Even small quantities reduce the braking torque significantly.

The nearest Bauer service partner can be found at www.bauergears.com.


11.3.1 Maintenance of brake types E003B and E004B

The brakes are low-maintenance.

1. Regularly check the wear of the brake disc by measuring the brake disc thickness.
 - Has the specified limit value d_{\min} , see Tab. 15, p. 45, been reached or even fallen short of?
 - Install a new brake disc as described.

Install new brake disc

1. Remove fan cover and fan blade (does not apply to non-ventilated motors).
2. Unscrew the fixing screws (5).
3. Pull off solenoid housing (8).
4. Remove dirt and debris.
5. Pull brake disc (1) off carrier.
6. Measure thickness of brake disc and replace as necessary.
7. Check armature disc (2) and friction plate (4), replace if there are large grooves.
8. Slide the brake disc (1) onto the carrier and check the radial play. If the play is large, replace the carrier.
9. Replace both seals (9) on the friction plate (4).
10. Slide the brake over the friction plate onto the motor end shield and fasten it with the fixing screw (5) and the USIT rings (10) that are also to be replaced. Tightening torque of fixing screws $M_A = 2.5 \text{ Nm}$
11. Reinstall disassembled parts in reverse order.



- 1 Brake disc
- 2 Armature disc
- 3 Compression spring
- 4 Friction plate
- 5 Fixing screw
- 6 Carrier
- 7 Brake coil
- 8 Solenoid housing
- 9 Seals
- 10 USIT ring
- 11 Shaft sealing ring
- 12 Snap ring
- 13 Manual release bracket (optional)
- 14 Manual release lever (optional)
- 15 Retaining bolt

11.3.2 Maintenance of single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A


Holding brakes are only used to secure a position that has been approached. In the event of an emergency, a slowdown function can be used. This slowdown function causes abrasion, which makes it necessary to check the air gap and perform additional maintenance work as necessary.



The air gap in these single-disc brakes cannot be adjusted due to the design of the solenoid housing.

Check air gap

1. If present, remove the fan cover.
2. Screw out screw plug (12) and check air gap with a feeler gauge.
3. After checking, secure the screw plug (12) again with locking varnish.
 - If the measured air gap corresponds to the nominal air gap, see Tab. 25, p. 50. No further work is necessary.
 - If there is wear: Further maintenance work is necessary, see chapter 11.3.3, p. 40.
4. Install removed parts in reverse order.



- 1 Solenoid housing
- 2 Brake disc
- 3 Compression spring
- 4.1 Sealing cap with closed brake
- 4.2 Shaft sealing ring with continuous shaft
- 5 Carrier
- 6 Armature disc
- 7 O-ring
- 8 Fixing screw with copper washer
- 9 Banjo screw
- 10 Key
- 11 Snap ring
- 12 Screw plug for checking air gap
- 13 Friction plate - only in motors with aluminium B-side end shield
- 14 Screw plug for checking microswitch setting
- 15 Microswitch (optional)
- 16 Manual release (optional)¹

11.3.3 Maintenance of single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A

i For pos. numbers, see chapter 11.3.2, p. 39

Check air gap

1. Remove the fan cover (for brakes under the fan cover).
2. Screw out screw plug (13) and check air gap with a feeler gauge.
 - In Tab. 27, p. 51, S_{Lmax} specifies the maximum permissible air gap.
3. After checking, secure the screw plug with locking varnish.

Brake maintenance


If the brake-related value is reached or exceeded, maintain the brake as follows:

1. Remove the fan blade (under the fan cover).
2. Unscrew fixing screws with copper ring (8) and pull the brake off the motor end shield.
3. Clean the brake and remove any debris.
4. Check armature disc (6) and friction plate (14) (only present on D..08 and D..09 motors) and replace if there are large grooves.
5. Pull brake disc (2) off carrier (5).
6. Slide on new brake disc (2). If there is increased play between the carrier and brake disc, pull off the carrier and replace it.
7. Replace O-ring (7) and copper washers under fixing screws (8).
8. Slide on the brake, tighten the screws (8), evenly offset with the corresponding torque, see Tab. 24, p. 49.
9. Install the fan blade and fan cover under the fan cover in reverse order.

11.3.4 Maintenance of double-disc holding brakes ZS300A ... ZS500A

Check air gap

1. Remove the fan cover.
2. Loosen fixing screws (8).
3. Remove dust cover (12).
4. Check air gap with feeler gauge, see figure below.
 - If the measured air gap corresponds to the nominal air gap, see Tab. 26, p. 50. No further work is necessary.
 - If there is wear, further maintenance work is required, see chapter 11.3.5, p. 41.
5. Install removed parts in reverse order.



11.3.5 Maintenance of double-disc service brakes ZSX300A ... ZSX500A



For pos. numbers, see chapter 11.3.4, p. 40

Check air gap

1. Remove the fan cover and fan blade.
2. Loosen fixing screws (14), take off plate (15), and remove cover (13).
3. Check air gap with feeler gauge, see figure in chapter 11.3.4, p. 40.
 - If the measured air gap corresponds to the nominal air gap, see the following table. No further work is necessary, reinstall disassembled parts in reverse order.
 - If the air gap is outside the tolerance limit, adjust the brake as follows.

Adjusting the brake

1. Loosen fixing screws (8) by turning counterclockwise 1/2 a turn.
2. Screw banjo screws (9) into solenoid housing (1) by turning them counterclockwise.
3. Screw in fixing screws (8) evenly in a clockwise direction, offset by 120°, until the nominal air gap is reached.
4. Unscrew banjo screws (9) clockwise until they are firmly against the counter-friction surface.
5. Tighten fixing screws with the specified torque, see Tab. 28, p. 51.
6. Check air gap again and adjust if necessary as described.
7. Install the disassembled parts in reverse order.

Once the minimum lining thickness has been reached, further adjustment of the air gap is no longer possible. Brake discs 2.1 and 2.2 and usually all other mechanical parts involved must be replaced.

- ▶ The drive can no longer be used as intended. Decommission the drive.
- ▶ Contact your nearest Bauer service partner, see www.bauergears.com.

11.4 Cleaning and maintenance

NOTICE

Improper cleaning of the paint layer

Corrosion protection is impaired. The drive or its surroundings may be damaged.

- ▷ Only use non-abrasive cleaning tools.

NOTICE

Penetration of liquid into device.

This may result in damage to the drives and the surrounding area/system.

- ▷ Water exposure only permitted in accordance with protection rating IP (rating plate).
- ▷ Avoid direct impacts to shaft seal (>IP65).

1. Perform cleaning work.
2. At the end of the cleaning cycle, remove any cleaner residue from the drive shaft sealing rings.

12 Decommissioning

Follow the instructions and notes for installation and commissioning in chapters 6.2, p. 20, 6.4, p. 22, 7, p. 32, and Tab. 8, p. 35, and proceed in reverse order.

13 Disassembly

Follow the instructions and notes for installation and commissioning in chapters 6.2, p. 20, 6.4, p. 22, 7, p. 32, and 8, p. 33, and proceed in reverse order.

14 Disposal

14.1 Packaging

Improper disposal of packaging materials can cause environmental damage.

The products are packaged in accordance with the necessary or prescribed requirements for the respective mode of transport.

► Dispose of non-reusable packaging materials in accordance with local waste or disposal regulations.

14.2 Motor

► Dispose of motor and its components separately according to material:

- Iron
- Aluminium
- Copper
- Plastic
- Electronic components

15 Spare parts and accessories

Our worldwide service team is always ready to provide advice and support for supplying spare parts. You can find the nearest service partner online at www.bauergears.com/sales-and-service/global-service/ under "Sales Locator".

Necessary spare parts can be requested and ordered from Bauer Gear Motor GmbH or one of our service partners.

Our website www.bauergears.com/sales-and-service/global-service/ allows you to select the necessary spare parts yourself using the "Spare Part Selector".

16 Technical data

16.1 General data and conditions of use

See the rating plate/type plate for the most important technical data on operating the motors.

These technical data and other contractually agreed data and properties form the basis and limit of the intended use.

Unless explicitly stated or agreed, the products can be operated without restriction and without taking special measures under the following environmental conditions:

Parameter	Value
Ambient temperature range	-20°C - +40°C
Installation altitude	1000 m above sea level

Tab. 11: Permissible ambient conditions

The power and torque data given on the rating plate is fully available at the output shaft.

Specific technical data can be requested from Bauer Gear Motor by specifying the serial and/or article number.

16.2 Motors

16.2.1 General

The power specified on the rating plate is fully available at the output shaft.

This applies to continuous operation (S1-100%) – unless otherwise specified – at a maximum ambient temperature of 40°C and up to an installation altitude of 1000 m above sea level.

If ambient conditions deviate, the values must be reduced.

The reduction factors can be requested from Bauer, specifying the exact ambient conditions.

Unless otherwise specified, a tolerance of +/- 5% applies to the rated voltage accordingly.

IEC 60034-1

16.2.2 Permanent magnet synchronous motors (PMSMs)

Parameter	Value
Parameter for optimal frequency inverter duty	See rating plate
Limit torques	See rating plate
Limit currents	See rating plate
Limit speed	See rating plate

Tab. 12: PMSM parameters

16.3 Motor attachments and accessories

16.3.1 External fan

For special applications, motors and brake motors starting at size D08 can be supplied with a mounted external fan.

A connection with multivolt design – operating capacitor for single-phase operation is installed as standard.

Operating mode	Frame size	Fan diameter [mm]	Voltage range		Max. permissible current		Max. power consumption	
			[V]		[A]		[W]	
			50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz
1 ~ ⊥ (Δ)	63	118	230-277	230-277	0.18	0.21	46	54
	71	132	230-277	230-277	0.18	0.21	48	56
	80	150	230-277	230-277	0.19	0.22	48	59
	90	169	220-277	220-277	0.29	0.23	59	61
	100	187	220-277	220-277	0.29	0.28	62	73
	112	210	220-277	220-277	0.27	0.36	64	88
	132	250	230-277	230-277	0.52	0.61	125	163
	160-200	300	230-277	230-277	1.05	1.52	246	390
3 ~ Y	63	118	346-525	380-575	0.09	0.08	28	29
	71	132	346-525	380-575	0.09	0.07	29	28
	80	150	346-525	380-575	0.09	0.07	33	36
	90	169	346-525	380-575	0.22	0.18	78	71
	100	187	346-525	380-575	0.21	0.18	80	80
	112	210	346-525	380-575	0.2	0.17	87	93
	132	250	346-525	380-575	0.37	0.32	160	180
	160-200	300	346-525	380-575	0.74	0.62	314	391
3 ~ Δ	63	118	200-303	220-332	0.15	0.14	28	29
	71	132	200-303	220-332	0.15	0.13	29	28
	80	150	200-303	220-332	0.16	0.13	33	36
	90	169	200-303	220-332	0.39	0.32	78	71
	100	187	200-303	220-332	0.37	0.3	80	80
	112	210	200-303	220-332	0.35	0.29	87	93
	132	250	200-303	220-332	0.64	0.55	160	180
	160-200	300	200-303	220-332	1.28	1.08	314	391

Tab. 13: Technical data, external fans

16.3.2 Brakes

The spring-loaded brakes with DC release solenoid of series E003B, E004B, ES(X)010A ... ES(X)300A, ZS(X)500A, EH(X)027A ... EH(X)400A **are not approved for use in potentially explosive atmospheres.**

Abbreviations

Abbreviation	Description
M_{Br}	Rated braking torque Braking torque tolerance: -10/+30% ¹⁾ , ²⁾ Braking torque tolerance: -20/+30% when run in. Up to -30% is possible when new. ³⁾
ZF	Number of springs Since different springs can be used with the E004B, the colour of the corresponding springs is also specified here.
W_{max}	Maximum permissible friction work per braking event ¹⁾ Maximum permissible friction work for emergency stop ²⁾
W_{th}	Maximum permissible friction work per hour
W_L	Maximum permissible friction work before brake disc replacement The stated values of W_L are guidelines which may vary considerably from one application case to another. Regular inspection of the brake disc thickness is recommended. ¹⁾ , ²⁾ Maximum permissible friction work until maintenance, i.e. brake disc replacement or air gap adjustment. The air gap can only be adjusted with type ZXS... brakes. The stated values of W_L are guidelines which may vary considerably from one application case to another. Regular inspection of the air gap is recommended. ³⁾
t_A	Response time for release with normal excitation. If the special overexcitation fast-acting rectifier overexcites, response times are approx. half as long.
t_{AC}	Response time during braking with AC-side switch-off, i.e. by interrupting the voltage supply of a separately supplied standard rectifier. When the rectifier is supplied with voltage from the motor terminals, significantly higher response times can be expected due to the remanence of the motor – depending on motor size and winding design.
t_{DC}	Response time during braking with interruption on DC side via mechanical switches. In the case of an electronic DC-side interruption by a special electronic or overexcitation fast-acting rectifier, response times are approx. 2-3 times longer. For the braking torque versions marked with *, which are only permitted with overexcitation fast-acting rectifiers, the values for t_A and t_{DC} apply for operation with overexcitation fast-acting rectifiers, i.e. t_A for overexcitation and t_{DC} for electronic direct current interruption. ²⁾ , ³⁾ Depending on the operating temperature, the state of brake disc wear, and manufacturing tolerances, the actual response times may deviate from the benchmark values specified here.
d_{min}	Minimum permissible brake disc thickness
P_{el}	Electrical power consumption of solenoid coil at 20°C. Depending on the voltage version of the coil, the actual power may differ from the benchmark given here.
¹⁾ Only for spring-loaded brakes with DC release solenoid of type E003B and E004B ²⁾ Only for holding brakes with emergency stop feature of type ES.../ZS... ³⁾ Only for service brakes of type ES(X).../ZS(X)...	

Tab. 14: Abbreviations for brake technical data

Spring-loaded brakes with DC release solenoid of type E003B and E004B

Type	M _{Br} [Nm]	ZF	W _{max} [*10 ³ J]	W _{th} [*10 ³ J]	W _L [*10 ⁶ J]	t _A [ms]	t _{AC} [ms]	t _{DC} [ms]	d _{min} [mm]	P _{el} [W]
E003B9	3	4	1.5	36	55	35	150	15	5.85	20
E003B7	2.2	3	1.8	36	90	28	210	20	5.75	20
E003B4	1.5	2	2.1	36	140	21	275	30	5.6	20
E004B9	5	4x red	2.5	60	50	37	125	15	5.87	30
E004B8	4	4x grey	3	60	100	30	160	18	5.75	30
E004B6	2.8	4x yellow	3.6	60	180	23	230	26	5.55	30
E004B4	2	2x grey	4.1	60	235	18	290	37	5.4	30
E004B2	1.4	2x yellow	4.8	60	310	15	340	47	5.2	30

Tab. 15: Technical data for spring-loaded brakes with DC release solenoid of type E003B and E004B

Spring-loaded brakes with DC release solenoid of type ES(X)010A ... ES(X)300A, ZS(X)300, and ZS(X)500A
Holding brakes with emergency stop feature of type ES.../ZS... Friction work, response times, performance

Type	M _{Br} [Nm]	W _{max} [*10 ³ J]	W _{th} [*10 ³ J]	W _L [*10 ⁶ J]	t _A [ms]	t _{AC} [ms]	t _{DC} [ms]	P _{el} [W]
ES/EH010AX	15*	3	-	-	110	-	30	35
ES/EH010A9	10	3	-	-	60	100	15	
ES/EH010A8	8	3	-	-	55	150	20	
ES/EH010A5	5	3	-	-	45	220	20	
ES/EH010A4	4	3	-	-	30	250	20	
ES/EH010A2	2.5	3	-	-	25	350	25	
ES027AX	32*	2.5	-	-	80	-	30	50
ES/EH027A9	27	2.5	-	-	120	100	15	
ES/EH027A7	20	2.5	-	-	100	130	20	
ES/EH027A6	16	2.5	-	-	80	170	25	
ES/EH040A9	40	3.5	-	-	100	100	20	65
ES/EH040A8	34	3.5	-	-	80	200	25	
ES/EH040A7	27	3.5	-	-	70	250	30	
ES/EH070AX	90*	3.5	-	-	120	-	40	85
ES/EH070A9	70	3.5	-	-	120	150	18	
ES/EH070A8	63	3.5	-	-	120	200	20	
ES/EH070A7	50	3.5	-	-	90	220	25	
ES/EH125A9	125	4.5	-	-	170	220	25	
ES/EH125A8	105	4.5	-	-	150	320	28	105
ES/EH125A7	85	4.5	-	-	135	350	30	
ES/EH125A6	70	4.5	-	-	120	440	35	
ES125A5	57	4.5	-	-	100	600	40	
ES125A3	42	4.5	-	-	90	700	45	
ES/EH200A9	200	8	-	-	400	150	22	
ES/EH200A8	150	8	-	-	280	250	35	
ES/EH200A7	140	8	-	-	200	320	35	
ES250A9	250	9	-	-	300	500	45	135
ES250A8	200	9	-	-	200	960	60	
ES250A6	150	9	-	-	160	1100	60	
ES250A5	125	9	-	-	150	1500	90	
ES250A4	105	9	-	-	130	1800	110	
ZS300A9	300	8	-	-	280	220	35	
ZS300A8	250	8	-	-	210	380	45	
EH400A9	400	10	-	-	300	600	60	180
EH400A7	300	10	-	-	200	850	75	
EH400A5	200	10	-	-	150	1400	85	
ZS500A9	500	9	-	-	320	320	50	100
ZS500A8	400	9	-	-	260	600	60	

* Requires overexcitation and is therefore only permissible with overexcitation fast-acting rectifiers

Tab. 16: Technical data for spring-loaded holding brakes with emergency stop feature of type ES.../ZS...

Service brakes of type ES(X).../ZS(X)... Friction work, response times, friction work performance, response times, performance

Type	M _{Br} [Nm]	W _{max} [10 ³ J]	W _{th} [10 ³ J]	W _L [10 ⁶ J]		t _A [ms]	t _{AC} [ms]	t _{DC} [ms]	P _{el} [W]
				without HL	with HL				
ESX/EHX010AX	15*	3	250	120	120	110	-	30	35
ESX/EHX010A9	10	3	250	120	120	60	100	15	
ESX/EHX010A8	8	3	250	150	150	55	150	20	
ESX/EHX010A5	5	3	250	240	240	45	220	20	
ESX/EHX010A4	4	3	250	300	240	30	250	20	
ESX/EHX010A2	2.5	3	250	390	240	25	350	25	
ESX027AX	27*	10	350	150	150	80	-	30	50
ESX/EHX027A9	22	10	350	150	150	120	100	15	
ESX/EHX027A7	16	10	350	300	300	100	130	20	
ESX/EHX027A6	13	10	350	350	350	80	170	25	
ESX/EHX040A9	32	20	450	420	420	100	100	20	65
ESX/EHX040A8	27	20	450	560	490	80	200	25	
ESX/EHX040A7	22	20	450	700	490	70	250	30	
ESX/EHX070AX	72*	28	550	700	700	120	-	40	85
ESX/EHX070A9	58	28	550	500	500	120	150	18	
ESX/EHX070A8	50	28	550	800	700	120	200	20	
ESX/EHX070A7	40	28	550	1200	700	90	220	25	
ESX/EHX125AX	100*	40	700	1900	1900	100	-	70	105
ESX/EHX125A9	85	40	700	1700	1700	150	320	28	
ESX/EHX125A8	70	40	700	1900	1700	135	350	30	
ESX/EHX125A7	58	40	700	2700	1700	120	440	35	
ESX125A5	45	40	700	3300	1700	100	600	40	
ESX125A3	34	40	700	3300	1700	90	700	45	
ESX/EHX200AX	160*	60	850	2000	2000	105	-	70	105
ESX/EHX200A9	120	60	850	1700	1700	280	250	35	
ESX/EHX200A8	110	60	850	2600	2600	200	320	35	
ESX250A9	200	84	1000	2800	2800	300	500	45	135
ESX250A8	160	84	1000	6800	5700	200	960	60	
ESX250A6	120	84	1000	8500	5700	160	1100	60	
ESX250A5	100	84	1000	11000	5700	150	1500	90	
ESX250A4	85	84	1000	11000	5700	130	1800	110	
ZSX300A9	250	60	850	1300	1300	280	220	35	75
ZSX300A8	200	60	850	2000	2000	210	380	45	
EHX400A9	320	120	1100	3000	3000	300	600	60	180
EHX400A7	240	120	1100	4800	4800	200	850	75	
EHX400A5	160	120	1100	6000	4800	150	1400	85	
ZSX500A9	400	84	1000	2800	2800	320	320	50	100
ZSX500A8	320	84	1000	4000	4000	260	600	60	

* Requires overexcitation and is therefore only permissible with overexcitation fast-acting rectifiers

Tab. 17: Technical data for spring-loaded service brakes of type ES(X).../ZS(X)...

No information on W_{th} and W_L, since holding brakes perform no or only insignificant friction work in normal operation.

16.3.3 Encoder system

Bauer standard encoders have a robust protective cover to prevent mechanical damage starting at motor size D05 (0.18 kW).

Parameter	Value
Robust bearings	
Protection rating	IP66
EMC tested	
Protected against polarity reversal	
Supply voltage	8-30 VDC
A-, B-, and N-track and inverted signals or output signals can be selected	
HTL output signals (TTL on request)	
1024 impulses per revolution	

Tab. 18: Special features – standard impulse encoders

Parameter	Value
Protection rating	IP66
Steps per revolution	8192 (13 bit)
Number of revolutions	4096 (12 bit)
Electronics version	SSI (Synchronous Serial Interface)
Output code type	Gray code
Supply voltage	11-27 V DC
Power loss (without load)	≤3 watts
Data output	RS-422 (2-wire)

Tab. 19: Special features – standard absolute encoders

Incremental rotary encoders

Parameter	Value
Supply voltage	8-30 V DC for HTL 5 V DC for TTL push-pull
Output signal	HTL A-, B-, N-track, optional TTL
Pulses per revolution	1024 optional 1...65536
Degree of protection	IP65, IP67 optional
Temperature range	-40 °C to +100 °C

Tab. 20: Technical data for incremental rotary encoders

Output voltage	RS 422 (TTL compatible)	RS 422 (TTL compatible)	Push-pull	Push-pull (7272)
Supply voltage	5 ... 30°VDC	5°V ±5%	8 ... 30°VDC	5 ... 30°VDC
Current consumption (without load) with inversion	Max. 70 mA	Max. 70 mA	Max. 70 mA	Max. 70 mA
Permissible load/channel	Max. ±20 mA	Max. ±20 mA	Max. ±20 mA	Max. ±20 mA
Pulse frequency	Max. 300 kHz	Max. 300°kHz	°Max. 160°kHz	°Max. 160°kHz
Signal level high	Min. 2.5 V	Min. 2.5 V	Min. UB - 3 V	Min. UB - 3 V
Signal level low	Max. 0.5°V	Max. 0.5°V	Max. 1°V	Max. 1 V

Tab. 21: Electrical parameters, incremental rotary encoders



For more data and information, see manufacturer's data sheet.

Absolute rotary encoders

Parameter	with PROFIBUS-DP interface	with SSI interface
Supply voltage	11 ... 27 V DC	
Current consumption without load	<350 mA	
Total resolution ¹⁾	≤33 bit	≤25 bit
Number of steps/revolutions, standard/extended ^{1), 2)}	≤8,192/≤32,768	≤8,192
Number of revolutions, standard/extended ¹⁾	≤4,096/≤256,000	
Profibus-DP V0 ³⁾	IEC 61158, IEC 61784	-
PNO Encoder Profile • Parameter ^{1), 3)}	Class 1 and 2 counting direction switchover, scaling function etc.	-
Output code ¹⁾	Binary, Gray, capped Gray	Binary, Gray, BCD
Output format ^{1), 4)}	-	Standard, fir tree, SSI+CRC, 26-bit repeat, variable number of data bits
Addressing ³⁾	3...99, adjustable via rotary switch	-
Baud rate ³⁾	9.6 kbit/s ... 12 Mbps	-
TR-specific functions ^{1), 3)}	speed output	-
Data width for actual position on bus ³⁾	≤25 bit	-
Clock input ⁴⁾	-	Optocoupler
Data output ⁴⁾	-	RS-422, 2-wire
Clock frequency ⁴⁾	-	80 kHz – 1 MHz
Monotime t_M ⁴⁾	-	16 μs ≤tM ≤25 μs, 20 μs typical
Negative values ^{1), 4)}	-	Sign + value, 2's complement
SSI or parallel special bits ^{1), 4)}	-	Limit switch, overspeed, direction indication, motion indication, error message, parity
V/R ^{1), 4)}	-	Counting direction
Preset ^{1), 4)}	-	Electronic adjustment
Logical state ⁴⁾	-	"0" < +2 V DC, "1" = supply voltage
Max. permissible speed	≤ 12,000 rpm	
Shaft load	Net weight	
Bearing life • RPM • Operating temperature	≥3.9 * 10 ¹⁰ rotations at ≤ 6,000 rpm ≤60 °C	
Shaft diameter [mm]	10 H7	
Permissible angular acceleration	≤10 ⁴ rad/s ²	
Moment of inertia	Typically 2.5 * 10 ⁻⁶ kg m ²	
Starting torque at 20°C	Typically 2 Ncm	
Mass	0.3 kg...0.5 kg	
Optional ⁴⁾ • Incremental signals, RS422 level	-	K1+, K1-, K2+, K2- with 1024 or 2048 impulses
¹⁾ Programmable parameter ²⁾ Differentiation only for PROFIBUS-DP interface ³⁾ Only for PROFIBUS-DP interface ⁴⁾ Only for SSI interface		

Tab. 22: Technical data for incremental rotary encoders



For more data and information, see manufacturer's data sheet.

16.3.4 Backstop (RR, RL)

With frequency inverter duty, note that correct operation of the backstop is only guaranteed at rotor speeds above 740/min.

16.4 Brake maintenance

The following abbreviations are used in the following:

Abbreviation	Description
M_{Br}	Rated braking torque
	Braking torque tolerance: -10/+30%
M_A	Tightening torque of fixing screws
d_{min}	Minimum permissible brake disc thickness
$s_{LN}^{2), 3), 4)}$	Nominal air gap when new: Tolerance: +0.15 mm except for EH400 and ZS800: Tolerance: +0.20 mm
$s_{Lmax}^{2), 3), 4)}$	Maximum permissible air gap
Manual release ^{2), 3), 4)}	Manual release
1) Only for spring-loaded brakes of series E003B or E004B 2) Only for single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A 3) Only for single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A 4) Only for double-disc service brakes ZSX300A ... ZSX500A	

Tab. 23: Abbreviations for brake maintenance

16.4.1 Spring-loaded brake of series E003B or E004B

Type	M_{Br} [Nm]	d_{min} [mm]	M_A [Nm]
E003B9	3	5.85	2.5
E003B7	2.2	5.75	2.5
E003B4	1.5	5.6	2.5
E004B9	5	5.87	2.5
E004B8	4	5.75	2.5
E004B6	2.8	5.55	2.5
E004B4	2	5.4	2.5
E004B2	1.4	5.2	2.5

Tab. 24: Technical data for maintenance of spring-loaded brakes of series E003B or E004B

16.4.2 Single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A

Typ	M _{Br} [Nm]	S _{LN} [mm]	S _{Lmax} [mm]		M _A [Nm]
			without HL	with HL	
ES/EH010AX	15* ¹⁾	0.2	0.6	0.6	6
ES/EH010A9	10	0.2	0.6	0.6	
ES/EH010A8	8	0.2	0.7	0.7	
ES/EH010A5	5	0.2	1.0	1.0	
ES/EH010A4	4	0.2	1.2	1.0	
ES/EH010A2	2.5	0.2	1.5	1.0	
ES027AX	32* ¹⁾	0.3	0.6	0.6	10
ES/EH027A9	27	0.3	0.6	0.6	
ES/EH027A7	20	0.3	0.9	0.9	
ES/EH027A6	16	0.3	1.0	1.0	
ES/EH040A9	40	0.3	0.9	0.9	10
ES/EH040A8	34	0.3	1.1	1.0	
ES/EH040A7	27	0.3	1.3	1.0	
ES/EH070AX	90*	0.3	1.0	1.0	25
ES/EH070A9	70	0.3	0.8	0.8	
ES/EH070A8	63	0.3	1.1	1.0	
ES/EH070A7	50	0.3	1.5	1.0	
ES/EH125A9	125	0.4	0.7	0.7	25
ES/EH125A8	105	0.4	1.2	1.2	
ES/EH125A7	85	0.4	1.3	1.2	
ES/EH125A6	70	0.4	1.7	1.2	
ES125A5	57	0.4	2.0	1.2	
ES125A3	42	0.4	2.0	1.2	
ES/EH200A9	200 ¹⁾	0.4	0.6	0.6	25
ES/EH200A8	150	0.4	0.9	0.9	
ES/EH200A7	140	0.4	1.2	1.2	
ES250A9	250	0.5	1.0	1.0	50
ES250A8	200	0.5	1.7	1.5	
ES250A6	150	0.5	2.0	1.5	
ES250A5	125	0.5	2.4	1.5	
ES250A4	105	0.5	2.4	1.5	
EH400A9	400	0.5	1.2	1.2	50
EH400A7	300	0.5	1.5	1.5	
EH400A5	200	0.5	1.7	1.5	

* nur mit MSG-Gleichrichter zulässig, da Übererregung erforderlich
¹⁾ Bremse mit Sonder-Federbohrung. Umbau auf ein anderes Bremsmoment ist nicht möglich.

Tab. 25: Technical data for maintenance of single-disc holding brakes ES010A ... ES250A, EH027A ... EH400A

16.4.3 Double-disc holding brakes ZS300A ... ZS500A

Type	M _{Br} [Nm]	S _{LN} [mm]	S _{Lmax} [mm]		M _A [Nm]
			without HL	with HL	
ZS300A9	300	0.5	0.9	0.9	25
ZS300A8	250	0.5	1.1	1.1	
ZS500A9	500	0.5	1.0	1.0	50
ZS500A8	400	0.5	1.2	1.2	

Tab. 26: Technical data for maintenance of double-disc holding brakes ZS300A ... ZS500A

16.4.4 Single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A

Type	M _{Br} [Nm]	S _{LN} [mm]	S _{Lmax} [mm]		M _A [Nm]	d _{min} [mm]	
			without HL	with HL		without HL	with HL
ESX/EHX010AX	15* ¹⁾	0.2	0.6	0.6	6	8.1	8.1
ESX/EHX010A9	10	0.2	0.6	0.6		8.1	8.1
ESX/EHX010A8	8	0.2	0.7	0.7		8	8
ESX/EHX010A5	5	0.2	1.0	1.0		7.7	7.7
ESX/EHX010A4	4	0.2	1.2	1.0		7.5	7.7
ESX/EHX010A2	2.5	0.2	1.5	1.0		7.2	7.7
ESX027AX	27* ¹⁾	0.3	0.6	0.6	10	10	10
ESX/EHX027A9	22	0.3	0.6	0.6		10	10
ESX/EHX027A7	16	0.3	0.9	0.9		9.7	9.7
ESX/EHX027A6	13	0.3	1.0	1.0		9.6	9.6
ESX/EHX040A9	32	0.3	0.9	0.9	10	11.9	11.9
ESX/EHX040A8	27	0.3	1.1	1.0		11.7	11.8
ESX/EHX040A7	22	0.3	1.3	1.0		11.5	11.8
ESX/EHX070AX	72*	0.3	1.0	1.0	25	13.8	13.8
ESX/EHX070A9	58	0.3	0.8	0.8		14	14
ESX/EHX070A8	50	0.3	1.1	1.0		13.7	13.8
ESX/EHX070A7	40	0.3	1.5	1.0		13.3	13.8
ESX/EHX125AX	100*	0.4	1.3	1.3	25	15.1	15.1
ESX/EHX125A9	85	0.4	1.2	1.2		15.7	15.7
ESX/EHX125A8	70	0.4	1.3	1.2		15.2	15.2
ESX/EHX125A7	58	0.4	1.7	1.2		15.1	15.2
ESX125A5	45	0.4	2.0	1.2		14.4	15.2
ESX125A3	34	0.4	2.0	1.2		14.4	15.2
ESX/EHX200AX	160* ¹⁾	0.4	1.0	1.0	25	17.4	17.4
ESX/EHX200A9	120	0.4	0.9	0.9		17.8	17.8
ESX/EHX200A8	110	0.4	1.2	1.2		17.5	17.5
ESX250A9	200	0.5	1.0	1.0	50	19.5	19.5
ESX250A8	160	0.5	1.7	1.5		18.8	19
ESX250A6	120	0.5	2.0	1.5		18.5	19
ESX250A5	100	0.5	2.4	1.5		18.1	19
ESX250A4	85	0.5	2.4	1.5		18.1	19
EHX400A9	320	0.5	1.2	1.2	50	19.3	19.3
EHX400A7	240	0.5	1.5	1.5		19.0	19.0
EHX400A5	160	0.5	1.7	1.5		18.8	19.0

* nur mit MSG-Gleichrichter zulässig, da Übererregung erforderlich
¹⁾ Bremse mit Sonder-Federbohrung. Umbau auf ein anderes Bremsmoment ist nicht möglich.

Tab. 27: Technical data for maintenance of single-disc service brakes ESX010A ... ESX250A, EHX027A ... EHX400A

16.4.5 Double-disc working brakes ZSX300A ... ZSX500A

Type	M _{Br} [Nm]	S _{LN} [mm]	S _{Lmax} [mm]		M _A [Nm]	d _{min} [mm]	
			without HL	with HL		without HL	with HL
ZSX300A9	250	0.5	0.9	0.9	25	17.8	17.8
ZSX300A8	200	0.5	1.1	1.1		17.7	17.7
ZSX500A9	400	0.5	1.0	1.0	50	19.75	19.75
ZSX500A8	320	0.5	1.2	1.2		19.65	19.65

Tab. 28: Technical data for maintenance of double-disc service brakes ZSX300A ... ZSX500A

BAUER GEAR MOTOR™

Regal Rexnord

regalrexnord.com bauergears.com

Germany

Eberhard-Bauer-Str. 37
73734 Esslingen - GERMANY
+49 711 3518 0

Slovakia

Továrenská 49
53 01 Zlaté Moravce - SLOVAKIA
+421 37 6926100

North America

701 Carrier Drive
Charlotte, NC 28216 - USA
+1 800-387-0130

China

18 Huanzhen Road,
Dabo Industry Zone, Shajing Town - Baoan District,
Shenzhen City, Guangdong Province - CHINA
+86 400 886 0365

The proper selection and application of products and components, including assuring that the product is safe for its intended use, are the responsibility of the customer. To view our Application Considerations, please visit <https://www.Regalrexnord.com/Application-Considerations>. To view our Standard Terms and Conditions of Sale, please visit <https://www.regalrexnord.com/Terms-and-Conditions-of-Sale>.

"Regal Rexnord" is not indicative of legal entity. Refer to product purchase documentation for the applicable legal entity.
Regal Rexnord and Bauer Gear Motor GmbH are trademarks of Regal Rexnord Corporation or one of its affiliated companies.
Images: Bauer-Archiv, Chr. Mayr, Precima
© 2026 Regal Rexnord Corporation, All Rights Reserved.
MCM-12600-BGM-EN-A4 05/26

The logo for Regal Rexnord, featuring a stylized 'R' icon followed by the text 'RegalRexnord™' in a bold, sans-serif font.