EB-375, EB-475, EB-650



EB-375, EB-475, EB-650

Component Parts

Item	Description	EB-375 Part No.	EB-375 Qty.	EB-475 Part No.	EB-475 Qty.	EB-650 Part No.	EB-650 Qty.
1	Armature & Carrier Assembly 1-1 Capscrew 1-2 Lockwasher 1-3 Autogap Accessory 1-4 Carrier 1-5 Armature	5380-101-006 797-1214 950-0102 5180-101-011 5380-295-002 5180-111-002	1 3 3 3 1 1	5381-101-004 797-1214 950-0102 5181-101-010 5381-295-003 5181-111-002	1 4 4 4 1 1	5382-101-005 797-0086 950-0103 5181-101-010 5382-295-002 5281-111-002	1 4 4 4 1 1
2	*Bushing			180-0410-180-0418 1/2” to 1” bore	1	180-0421-180-0435 1/2” to 1-3/8” bore	1
3	Hub 1/2" Bore 5/8" Bore	 540-0520 540-0519	1	540-0524	1	540-0523	1
4	Set Screw 1/2" Bore 5/8" Bore	 797-0368 797-0366	2				
5	Retainer Ring	748-0101	1	748-0102	1	748-0104	1
6	Ball Bearing	166-0150	1	166-0110	1	166-0104	1
7	Retainer Ring	748-0018	1	748-0002	1	748-0004	1
8	Magnet 6 volt 24 volt 90 volt	 5380-631-003 5380-631-004 5380-631-002	1	 5381-631-003 5381-631-004 5381-631-002	1	 5382-631-003 5382-631-005 5382-631-002	1
9	Locknut	661-0050	1	661-0051	1	661-0004	1
10	Washer	950-0029	1	950-0026	1	950-0030	1
11	Rod End Bearing	166-0186	1	166-0187	1	166-0188	1
12	Torque Arm Rod Assembly	5380-112-001	1	5381-112-001	1	5382-112-001	1
13	Terminal Accessory	5311-101-001	1	5311-101-001	1	5311-101-001	1
14	Adapter (optional) 5/8" Motor Shaft 7/8" Motor Shaft 1-1/8" Motor Shaft 1-3/8" Motor Shaft 1-5/8" Motor Shaft	 5380-101-005 5380-101-004	1	 5381-101-003	1	 5382-101-003 5382-101-002	1
15	Conduit Box	5200-101-010	1	5200-101-010	1	5200-101-010	1

*See page 198 for specific part numbers.
Refer to Service Manual P-211.
These units when used with the correct Warner Electric conduit box, meets the standards of UL508 and are listed under guide care #NMTR, file #59164.

c UL us

Service Parts