

Modified FSBR Brakes

MOBILE X-RAY MACHINES

PROBLEM

A medical imaging technology leader required an electric brake for its mobile X-Ray machines. The brakes are needed to provide reliable parking/holding functionality to ensure that the machine does not move during the imaging process. Two brakes are mounted directly to the cart's twin rear-wheel traction drives.

SOLUTION

Based on previous successful collaborations, the OEM contacted Warner Electric™ for a braking solution. After a review of the minimal space requirements, Warner engineers recommended the use of FSBR reverse mounted, spring applied brakes with a 30 in.lbs. static torque rating.

Low-profile, power-off FSBR brakes are designed specifically for applications with limited space (short axial length) or for motors with short shaft extensions. When mounted, the hub is installed on the motor shaft first, then the brake is installed over the hub and attached to the motor. The 2.4 in. dia. brakes supplied featured hex drive hubs and custom voltage coils.



HIGHLIGHTS

- Reverse mounted, spring applied friction brakes
- 30 in.lbs. static torque rating
- Compact, low profile design
- Custom voltage coils

Regal Rexnord

Contact us: 1-800-825-9050

warnerelectric.com | regalrexnord.com

The proper selection and application of products and components, including assuring that the product is safe for its intended use, are the responsibility of the customer. To view our Application Considerations, please visit <https://www.regalrexnord.com/Application-Considerations>.

To view our Standard Terms and Conditions of Sale, please visit <https://www.regalrexnord.com/Terms-and-Conditions-of-Sale>.

"Regal Rexnord" is not indicative of legal entity. Refer to product purchase documentation for the applicable legal entity. Regal Rexnord and Warner Electric are trademarks of Regal Rexnord Corporation or one of its affiliated companies.

© 2020, 2026 Regal Rexnord Corporation, All Rights Reserved.

MCCSS-P-7825-WE-EN-US 01/26

